

CD PLAYER DAC LIST 02/2011

A

ACCUPHASE DAC10 2 x AD1853
 ACCUPHASE DAC20 2 x AD1955
 ACCUPHASE DC-61 12 x PCM1702 – SM5843AP
 ACCUPHASE DC-81 8 x ICL8010ACPD – 2 x SM5801P
 ACCUPHASE DC-81L 10 x ICL8010ACPD – SM5803AP
 ACCUPHASE DC-91 16 x PCM63P-K
 ACCUPHASE DC-101 6 x AD1853
 ACCUPHASE DC-330 6 x AD1853
 ACCUPHASE DC-801 8 x AD1955
 ACCUPHASE DP-11 2 x PCM58P-S – SM5803AP Sony KSS-190A
 ACCUPHASE DP-55 6 x PCM1702 – SM5843AP Sony KSS-240A
 ACCUPHASE DP-55V 2 x AD1853 Sony KSS-240A
 ACCUPHASE DP-57 2 x PCM1796 – AK4114VQ Sony KSS-240A
 ACCUPHASE DP-60 2 x PCM58P-K – SM5803AP Sony KSS-190A
 ACCUPHASE DP-65 8 x PCM1702 – SM5843AP Sony KSS-272A
 ACCUPHASE DP-65V 8 x PCM1702 – SM5843AS Sony KSS-272A
 ACCUPHASE DP-67 4 x AD1955 – AK4114VQ Sony KSS-240A
 ACCUPHASE DP-70 8 x ICL8010ACPD Sony BU-1C
 ACCUPHASE DP-70V 10 x ICL8010ACPD – SM5803AP Sony KSS-190A
 ACCUPHASE DP-75 16 x PCM1702 – SM5843AP Sony KSS-272A
 ACCUPHASE DP-75V 6 x AD1853 Sony KSS-272A
 ACCUPHASE DP-77 4 x AD1853 SACD
 ACCUPHASE DP-78 6 x AD1955 – AK4114VQ SACD
 ACCUPHASE DP-80 Transport – CX23035 Sony BU-1C
 ACCUPHASE DP-80L Transport – CXD1125QZ Sony KSS-190A
 ACCUPHASE DP-85 6 x AD1853 NJM4580 SACD Sony KHM-230AAA
 ACCUPHASE DP-90 Transport – CXD2500BQ PCM63 Sony KSS-272A
 ACCUPHASE DP-100 Transport SACD Sony KHS-180A
 ACCUPHASE DP-400 2 x PCM1796 Sony KSS-213C
 ACCUPHASE DP-500 4 x PCM1796 Sony KSS-213C
 ACCUPHASE DP-600 6 x AD1955 SACD Sony KHM-230AAA
 ACCUPHASE DP-700 8 x AD1955 SACD Sony KHM-230AAA
 ACCUPHASE DP-800 Transport SACD Sony KHM-230AAA
 ACOUSTIC RESEARCH CD-04 2 x TDA1540P – SAA7030 CDM-2
 ACOUSTIC RESEARCH CD-06 TDA1541 CDM-2
 ACOUSTIC RESEARCH CD-06SE TDA1541A CDM-4
 ACOUSTIC RESEARCH CD-07 TDA1541 – SAA7220 CDM-4
 ACOUSTIC RESEARCH CD-07SE SAA7350 CDM-4
 ADC CD 250XR PCM54 KSS-123A
 ADC CD-350XR PCM54HP KSS-123A
 ADCOM GCD-575 TDA1541A KSS-212B
 ADCOM GCD-600 TDA1541 KSS
 ADCOM GCD-750 4 x PCM1702 – PMD100 Panasonic RAE0113Z
 ADCOM GDA-600 2 x PCM63P – DF1700P – CS8412-CP D/A converter
 ADCOM GDA-700 2 x PCM1702 – PMD100 D/A converter
 ADS CD3 2 x CX20152 – CX23034 KSS-121A / KSS-123A
 ADVANTAGE CD1 2 x PCM1702 – NPC filter Pioneer Stable Platter PEA1343
 AIWA DX-770 CX20017 KSS-123A
 AIWA DX-1500 CX20017 KSS-123A
 AIWA DX-1200 PCM53JP-V 87-046-260-010
 AIWA DX-1000 PCM53JG-V 87-046-260-010
 AIWA DX-M45 TDA1541 CDM-4/25
 AIWA DX-M75 LC7881 KSS-150A
 AIWA XC-002 1 x PCM56P KSS-150A
 AIWA XC-003 1 x PCM56P – PD0036 KSS-150A
 AIWA XC-004 2 x PCM56P KSS-150A
 AIWA XC-005 2 x PCM58P – YM3414 KSS-150A
 AIWA XC-007 2 x PCM56P-K KSS-151A
 AIWA XC-300 TC9237N KSS-210A
 AIWA XC-333 μPD6376 KSS-210A
 AIWA XC-500 TC9237N KSS-210A
 AIWA XC-777 2 x PCM61P KSS-210B
 AIWA XC-950 SAA7350 – SM5840BS KSS-210A / KSS-212A
 A&D DP-7000 2 x PCM56P KSS-151A
 A&D DP-9000 2 x PCM56P KSS-151A
 AKAI CD25/26/27/36 KSS210A TDA1543A?
 AKAI CD-32 PCM56P KSS-150A
 AKAI CD37 PCM67P KSS210A NJM4558
 AKAI CD52 KSS210A
 AKAI CD55 AD1856 KSS210A
 AKAI CD57 PCM67PJ KSS210 CXD1167Q
 AKAI CD62 BO38258J
 AKAI CD650/70 KSS210A
 AKAI CD69 PCM63 KSS210A
 AKAI CD-A70 MB84053B KSS123A//BO367214J
 AKAI CD-M839 PCM56
 AKAI CD79 KSS210A
 AKAI CD750 KSS210A
 AKAI CD73/93 PCM56 KSS155A(884806401)
 ALBA CD420 PCM54
 ALCHEMIST NEXUS APD32A 2x TDA1549
 AMC CD6 SAA7323GP – SAA7220P/B CDM-4/19
 AMC CDM7 SAA7323GP CDM-4/19
 AMC CD8A MN6474(Technics MASH) KSS-210A
 AMC CD8B PCM1716 KSS-213
 AMC CD8D 2 x PCM1730

AMC CD9 MN6474 – CDX1167Q KSS-210A
 AMC CD60 PCM1716
 ANTHEM CD1 PCM1702
 ARCAM ALPHA 5 TDA1541 CDM9
 ARCAM ALPHA 5 PLUS TDA7310 SAA7220P/B TDA1541A CDM9
 ARCAM ALPHA 6 SM5864
 ARCAM ALPHA 7 PCM1710
 ARCAM ALPHA 7SE PCM1716
 ARCAM ALPHA 8 SM5864AP
 ARCAM ALPHA 9 dCS RingDAC
 ARCAM CD72 PCM1716
 ARCAM CD92 dCS RingDAC
 ARCAM DELTA 70.2 TDA1541-S1 cdm4/31
 ARCAM DELTA 70.3 LM627
 ARCAM DELTA 270 PCM69
 ARCAM DELTA BOX 5 PCM67
 ARISTON CD PLAYER TDA1541A-S1 (Single Crown) CDM-4/19
 ARISTONA CD1202 2 x TDA1540D – SAA7030 CDM-0
 ARISTONA CD1204 2 x TDA1540P – SAA7030 CDM-1
 ASSEMBLAGE DAC-1.5 2 x PCM1702 – PMD100 – CS8412 D/A converter
 ASSEMBLAGE DAC-2 2 x PCM1702 – PMD100 – CS8412-CP D/A converter
 ASSEMBLAGE DAC-2.6 2 x PCM1704 – PMD100 – CS8412-CS D/A converter
 ASSEMBLAGE DAC-2.7 2 x PCM1704 – PMD200 – CS8414-CS D/A converter
 ASSEMBLAGE DAC-3 4 x PCM1704 – PMD100 – CS8414-CS D/A converter
 ASSEMBLAGE DAC-3.1 4 x PCM1704 – PMD200 D/A converter
 ATOLL CD 200 PCM1794 VAM 1202/12
 AUDIO AERO CAPITOLEAD1853 Philips CD-Pro 2 (VAM 1254)
 AUDIO AERO CAPITOLE REFERENCE PCM1792 + Anagram S.T.A.R.S. Philips CD-Pro 2M (VAM 1254)
 AUDIO AERO PRESTIGE SACD PCM1792 SACD
 AUDIO AERO PRIMA PCM1739 VAM 1201
 AUDIO AGILE JOCKER'S CD SM5872BS CDM 12
 AUDIO ALCHEMY ACD-1 AD1864N
 AUDIO ALCHEMY DDE v1.0 SAA7323GP – SAA7274P D/A converter
 AUDIO ALCHEMY DDE v1.2 2 x AD1862 – PMD100 D/A converter
 AUDIO ALCHEMY DDE v2.0 SAA7350GP – DF1700P – YM3623B D/A converter
 AUDIO ALCHEMY DDE v3.0 2 x AD1862N – PMD100 – CS8412-CP D/A converter
 AUDIO ALCHEMY D-I-T-B 2 x AD1860 – YM3433 D/A converter
 AUDIO ALCHEMY DDS III Transport KSS-240A
 AUDIO ALCHEMY DDS PRO Transport PEA1179 Stable Platter
 AUDIO ALCHEMY XDP TDA1547 – SAA7350 – DF1700P D/A converter
 AUDIO ANALOGUE MAESTRO AD1855
 AUDIO ANALOGUE PAGANINI CS4390 KSS-210
 AUDIO CRAFTERS GUILD X-DAC 3.0 CS4328-CP – AD1891JN
 AUDIO DYNAMICS CD-2000E 1 x PCM56P-J – SM5807EP CDM 12
 AUDIO INNOVATIONS ALTO PCM1716
 AUDIO NOTE CD-1 PCM1710 Sony / Samsung SOH-A1
 AUDIO NOTE CD-2 AD1865 – SM5843AP KSS-210 / SOH-A1
 AUDIO NOTE CD-2.1x AD1865N KSS-213
 AUDIO NOTE CD-3 AD1865 – SM5843 SOH-A1
 AUDIO NOTE CD-3.1x AD1865N KSS-213
 AUDIO NOTE CDT-ZERO PCM1710 KSS-213
 AUDIO NOTE DAC-1 PCM63P
 AUDIO NOTE DAC-2 PCM63P-J
 AUDIO NOTE DAC-3 PCM63P-K
 AUDIO NOTE DAC-4 PCM63P-K
 AUDIO NOTE DAC-5 AD1862N-J
 AUDIO RESEARCH CD1 SAA7341 CDM 12
 AUDIO RESEARCH CD2 CS4329-KP CDM 12.1
 AUDIO RESEARCH CD3 CS4396 Philips CD-Pro (VAM 1252)
 AUDIO RESEARCH CD3 Mk II CS4396 Philips CD-Pro 2 (VAM 1254)
 AUDIO RESEARCH CD5 PCM1792 Philips CD-Pro 2M (VAM 1254)
 AUDIO RESEARCH CD7 CS4396 Philips CD-Pro 2LF (VAM 1254)
 AUDIO RESEARCH CD8 PCM1792 Philips CD-Pro 2LF (VAM 1254)
 AUDIO RESEARCH CDT1 Transport CDM 12.1
 AUDIO RESEARCH DAC1-20 UltraAnalog D20400A – SM5803APT
 AUDIO RESEARCH DAC2 UltraAnalog D20400A – NPC filter
 AUDIO RESEARCH DAC3 CS4328-KP – CS8412
 AUDIO RESEARCH DAC7 PCM1792 – PCM2707
 AUDIO SYNTHESIS DA-X 1 x D20400A / 2x PCM63P - SM5803APT
 AUDIO SYNTHESIS DAX-2 2 x UA D20400A – SM5842AP / PMD100
 AUDIO SYNTHESIS DAX-Decade 2 x UA D20400A – PMD100 – CS8412-CP
 AUDIOLAB 8000 CD CS4329
 AUDIOLAB 8000 CDM Transport CDM-9 Pro
 AUDIOLAB 8000 CDM II Transport Philips CD-Pro (VAM 1252)
 AUDIOLAB 8000 DAC TDA1547 – SAA7350 – SM5843AP
 AUDIOLAB 8200 CDQ SAA7824 AM5810 (SABRE ES9018) AD744 NE5534
 AVI SC2000MC PCM63P – DF1700 – SAA7310 CDM-9/44 / CDM 12.1
 AYON CD-1 CS4398 KSS-213Q
 AYON CD-3 CS4398 KSS-213Q
 AYRE CX-7 PCM1738 – DF1706 DVD-ROM DVS DSL-710A
 AYRE D-1 4 x PCM1704 – DF1704 DVD
B
 BALANCED AUDIO TECH. VK-D5 x PCM63P-K – PMD100 CDM 12
 BANG & OLUFSEN BEOGRAM CD50 PCM53-JP-V 8055032
 BANG & OLUFSEN BEOGRAM CDX 2 x TDA1540P – SAA7030 CDM-1
 BANG & OLUFSEN BEOGRAM CDX2 TDA1541A – SAA7220P/B CDM-2/10
 BANG & OLUFSEN BEOGRAM CD3300 TDA1541 CDM-2/10
 BANG & OLUFSEN BEOGRAM CD5500 TDA1541A – SAA7220P/B CDM-4/11
 BEL CANTO CD1 PCM1792 Philips

BEL CANTO	DAC 3	PCM1792		
BENCHMARK	DAC 1	AD1853		
BERENDSEN	CDP I	CS4390		
BERENDSEN	CDP II	CS4327		
BESTAR CD 900	YM3020 - YM3805	Hitachi HOP-M3		
BETALASER	ADD 200	2 x TDA1540D - SAA7030	HLPL 030010 (Toshiba OPH-31)	
BLAUPUNKT	CP-2650	PCM54HP - YM2601	MLP-3C	
BLAUPUNKT	CP-2790	LC7881 - CXD1135QZ	KSS-210A	
BLAUPUNKT	CP-2800	PCM53JG-V - TM5001 (HD61902H)	Hitachi (DA-1000)	
BLAUPUNKT	CP-2850	TDA1541 - SAA7220P/A	CDM-2/10 / CDM-4/11	
BLAUPUNKT	CP-2890	Artech	2 x PCM56P - SM5807BP	KSS-150A
BLAUPUNKT	CP-2950	Artech	PCM54HP - YM2601	MLP-3C
BLAUPUNKT	CP-2990	Artech	2 x PCM56P-J	KSS-152A
BOW TECHNOLOGIES	Wizard	TDA1305	CDM 12 Pro	
BOW TECHNOLOGIES	ZZ-Eight	4 x PCM1702-K - PMD100	CDM 12 Pro	
BRANDT DAD 001	Hitachi HA16633P / PCM53JG-V		Hitachi (DA-1000)	
BRANDT DAD 002	PCM53JG-V	4972541		
BRAUN CD2/3	2 x PCM56P-J - CXD1135QZ		KSS-152A	
BRAUN CD3	2 x CX20152 - CX23034		KSS-121A / KSS-123A	
BRAUN CD4	2 x PCM56P-J - YM3414		KSS-123A	
BRAUN CD4/2	2 x PCM61P - YM3434		KSS-152A	
BROADCAST ENGINEERS	D2A	CS4328-KP - CS8412-CP		
BRYSTON BDA-1	2 x CS4398			
BURMESTER 001	4 x PCM1704	Philips CD-Pro (VAM 1252)		
BURMESTER 006	2 x PCM1704	Philips VAM 1250		
BURMESTER 979	Transport CDM-9 Pro			
C				
CALIFORNIA AUDIO LABS	ALPHA	CS4328-KP - CS8412-CP		D/A converter
CALIFORNIA AUDIO LABS	ARIA MK III	2 x PCM58P-K	SOAD70A	
CALIFORNIA AUDIO LABS	CL10	PCM1702 + HDCD		
CALIFORNIA AUDIO LABS	CL15	PCM1702 + HDCD		
CALIFORNIA AUDIO LABS	DELTA	Transport Panasonic RAE0113Z		
CALIFORNIA AUDIO LABS	DX-1	MN66271 Panasonic RAE0113Z		
CALIFORNIA AUDIO LABS	GAMMA	PCM1710U - CS8412-CP		D/A converter
CALIFORNIA AUDIO LABS	ICON	2 x PCM61P - SM5813AP	SOAD70A	
CALIFORNIA AUDIO LABS	ICON MK II	2 x PCM1702 - PMD100 + HDCD		Panasonic RAE0113Z
CALIFORNIA AUDIO LABS	SIGMA	CS4328 - CS8412-CP		D/A converter
CALIFORNIA AUDIO LABS	SIGMA II	CS4328-KP - CS8412-CP		D/A converter
CALIFORNIA AUDIO LABS	TEMPEST	2 x TDA1540 - SAA7030	CDM-2	
CALIFORNIA AUDIO LABS	TEMPEST II	TDA1541 - SAA7220P/A	CDM-4/11	
CAMBRIDGE AUDIO AZUR	340C	CS4338		
CAMBRIDGE AUDIO AZUR	540C	1 x Wolfson WM8716	Sony KSS-213	
CAMBRIDGE AUDIO AZUR	540C V2	1 x Wolfson WM8740	Sanyo SF-P101N	
CAMBRIDGE AUDIO AZUR	640C	1 x Wolfson WM8740	Sony KSS-213C	
CAMBRIDGE AUDIO AZUR	640C V2	2 x Wolfson WM8740	Sanyo SF-P101N	
CAMBRIDGE AUDIO AZUR	840C	2 x AD1955	Sanyo SF-P101N	
CAMBRIDGE AUDIO	CD1	6 x TDA1540	CDM-1	
CAMBRIDGE AUDIO	CD2	4 x TDA1541 - SAA7220	CDM-2/10	
CAMBRIDGE AUDIO	CD3	4 x TDA1541A - SAA7220P/B	CDM-1 Mk II	
CAMBRIDGE AUDIO	CD3M	Transport CDM-1 Mk II		
CAMBRIDGE AUDIO	CD4	TDA1305 Sanyo		
CAMBRIDGE AUDIO	CD4SE	CS4327KS	CDM 12	
CAMBRIDGE AUDIO	CD6	2 x TDA1305T	Sanyo SF-91	
CAMBRIDGE AUDIO	D300SE	CS4338	Sony	
CAMBRIDGE AUDIO	D500	CS4327	KSS-213	
CAMBRIDGE AUDIO	D500SE	CS4391	KSS-213	
CAMBRIDGE AUDIO	DAC 3	2 x TDA1305T		D/A converter
CAMBRIDGE AUDIO	DAC 3 D/A	4 x TDA1541A-S1		D/A converter
CAMBRIDGE AUDIO	DACMAGIC 1	2 x TDA1305		D/A converter
CAMBRIDGE AUDIO	DACMAGIC 2	2 x TDA1305		D/A converter
CAMBRIDGE AUDIO	DISCMAGIC 1	Transport - CXD1167	Sanyo SF-91	
CAMBRIDGE AUDIO	S700	SAA7350		D/A converter
CARAT C57	PCM1732U	VAM 1202		
CARAT C57	MK2	PCM1796		
CARVER DTL-50	PCM54HP - YM2601		MLP-3C	
CARVER SD/A 360	SAA7350 - YM7121C			
CARVER SD/A 450	MN6474			
CARVER TL-3100	LC7881-C			
CARY AUDIO DESIGN	CD-300	2 x PCM63P-K - PMD100	Pioneer Stable Platter PEA1030	
CARY AUDIO DESIGN	CD-301	SM5872		
CARY AUDIO DESIGN	CD-303	2 x PCM1704U - PMD100	VAM 1202/12	
CARY AUDIO DESIGN	CD 303/200	2 x PCM1704U-K - PMD100	VAM 1202	
CARY AUDIO DESIGN	CD 303/300	2 x PCM1792U	DVD-ROM DVS DSL-710ALT	
CARY AUDIO DESIGN	CD 306	4 x PCM1794U	SCD-1	
CARY AUDIO DESIGN	CD-308	PCM1704U + HDCD	CDM 12	
CARY AUDIO DESIGN	CDP 1	2 x PCM1792	DVD-ROM DVS DSL-710ALT	
CASEA CEPHEUS	CS43122 - CS8416			D/A converter
CASEA CORONA	CS4390-KP - CS8412			D/A converter
CAYIN CD-50T	PCM1732	KSS-213Q		
CAYIN CDT-15A	PCM1732	Philips CDM 12.10		
CAYIN CDT-17A	2 x PCM1792	Philips VAM 1206		
CAYIN CDT-23	PCM1792	KSS-213		
CAYIN VENUS CD-10i	PCM1792			
C.E.C. 530CDII	Y3015			
C.E.C. 540CD / 640CD	LC7880 ?	Sanyo SF-P1		
C.E.C. 630CD	PCM56P - YM3815	Sanyo SF-86		
C.E.C. 680CD	LC7881	Sanyo SF-P1		
C.E.C. 780CD	LC7881 - YM7121R (filter)	Sanyo SF-P1		
C.E.C. 880CD	LC7881 - YM7121B (filter)	Sanyo SF-P1 / SF-90		

CEC	CD2100	TDA1305T	CEC-Sanyo SF-P1 / SF-90	
CEC	CD3100	TDA1305T / PCM67U	CEC-Sanyo SF-P1 / SF-90	
CEC	CD3300	PCM1738	CEC-Sanyo SF-P101N	
CEC	CD3300R	PCM1796	CEC-Sanyo SF-P101N	
CEC	CD5300	2 x PCM1796	CEC-Sanyo SF-P101N	
CEC	DA53	2 x PCM1796 + PCM2906	D/A converter	
CEC	DX1N	2 x PCM1792	D/A converter	
CEC	DX71 Mk II	2 x SM5865CM	D/A converter	
CEC	TL0	Transport	CEC-Sanyo SF-90	
CEC	TL1	Transport	CEC-Sanyo SF-90	
CEC	TL2	Transport	CEC-Sanyo SF-90	
CEC	TL51XR	2 x PCM1796	CEC-Sanyo SF-P101N	
CEC	TL51XZ	SM5865CM	CEC-Sanyo SF-P101N	
CEC	TL51Z	4 x PCM1704 - DF1706	CEC-Sanyo SF-P1	
CEC	TL51Z Mk II	SM5865CM	CEC-Sanyo SF-P101N	
CEC	TL53Z	2 x PCM1792		
CEC	TL5100Z	2 x PCM1702 - SM5843AP	CEC-Sanyo SF-P1	
CLAIRTONE	MODEL 2704	2 x TDA1540D - SAA7030	HLPL 030010 (Toshiba OPH-31)	
CLASSE AUDIO	CDP-1	UltraAnalog D20400 - PMD100	CDM 12.4	
CLASSE AUDIO	CDP-1.5	2 x PCM1704	CEC-Sanyo SF-P	
CLASSE AUDIO	CDP.3	2 x PCM1702 - PMD100	CEC-Sanyo SF-P1	
CLASSE AUDIO	CDP.5	PCM1702	CDM 12.4	
CLASSE AUDIO	CDP-10	2 x PCM1738	Philips VAE 1250	
CLASSE AUDIO	CDP-100	2 x PCM1738 - PMD200	Philips VAE 1250 Pro	
CLASSE AUDIO	CDP-102	1 x CS4398	DVD-ROM TEAC	
CLASSE AUDIO	CDP-202	2 x PCM1792	DVD-ROM TEAC	
CLASSE AUDIO	CDP-300	3 x CS4398	DVD-ROM TEAC	
CLASSE AUDIO	CDP-502	3 x PCM1792	DVD	
CLASSE AUDIO	CDT-1	Transport	CDM 12.4	
CLASSE AUDIO	DAC-1	2 x UltraAnalog D20400A - PMD100	D/A converter	
COMBAK REIMYO	DAP-777	JVC - JCE4315 - K2	D/A converter	
CONDOR CD950	YM3020			
CONSONANCE	CD 120	CS4396 / TDA1543	KSS-213	
CONSONANCE	DROPLET	CDP5.0 CS4398	KSS-213 / CDM 12	
CONTINENTAL EDISON	DAD 9370	Hitachi HA16633P / PCM53JG-V	Hitachi (DA-1000)	
CONTINENTAL EDISON	DAD 9474	PCM53JG-V	4972541	
COPLAND	CDA 266	2 x PCM63P - PMD100	KSS-240A	
COPLAND	CDA 277	2 x PCM63P - PMD100	VRDS CMK-4 - KSS-240A	
COPLAND	CDA 288	4 x PCM63P-K - PMD100	VRDS CMK-4 - KSS-240A	
COPLAND	CDA 289	4 x PCM63P - PMD100	KSS-240A	
COUNTERPOINT	DA-10E-AD	2 x AD1862N - DF1700P - CS8412-CP	D/A converter	
COUNTERPOINT	DA-10E-BB	PCM69P	D/A converter	
COUNTERPOINT	DA-10E-CS	CS4328	D/A converter	
COUNTERPOINT	DA-10E-UA	UltraAnalog D20400	D/A converter	
COUNTERPOINT	DA-11	Transport	CDM 12	
CREEK	CD42 Mk 2	CS4328		
CREEK	CD43	CS4390	CDM 14 Sony	
CREEK	CD43 Mk 2	CS4396	CDM 12	
CREEK	CD50	CS4396	CDM 12	
CREEK	CD50 Mk 2	CS4396	DVD-ROM DVS DSL-710A	
CREEK	CD53	CS4396	CDM 12	
CREEK	CD60	TDA1541A-S1 - SAA7220P/B	CDM-4/14	
CREEK	DAC 60	2 x PCM63P-K - DF1700P - YM3623B	D/A converter	
CREEK	DESTINY	CS4396		
CREEK	EVO CDP	PCM1738	Philips VAM 1201	
CREEK	EVOLUTION 2	PCM1796		
CROWN	AVC-9500	AD1864		
CROWN	CD2111R	LC7881		
CYRUS	CD7	PCM1716		
CYRUS	dAD1	TDA1311		
CYRUS	dAD3	TDA1305		
CYRUS	dAD3Q	AD1861		
CYRUS	dAD7	AD1861		

D

DBX	DX 5	2 x PCM56P	Sanyo SF-86	
DBX	DX 900	2 x PCM56P-S - SM5804B	KSS-152A	
DENON	CDR-1000	AD1855	Writer	
DENON	DA-500	2 x PCM1702-J - SM5845AF - YM3623B	D/A converter	
DENON	DA-S1	4 x PCM1702-K - SM5843AP	D/A converter	
DENON	DP-S1	Transport	KSS-151A	
DENON	DAP-2500A	2 x PCM61P - SM5813AP - YM3623B	D/A converter	
DENON	DAP-5500	4 x PCM56P-K - SM5804D	D/A converter	
DENON	DCD-7.5	2 x PCM56P-L - SM5840CP	KSS-240A	
DENON	DCD-73M	1 x PCM56P	KSS-150A	
DENON	DCD-201SA	2 x PCM1702-L		
DENON	DCD-210	2 x PCM56P-L - CXD2551P	KSS-210A	
DENON	DCD-300	PCM54HP	KSS-123 / KSS-152	
DENON	DCD-335	PCM1716E	KSS-210A	
DENON	DCD-425	PCM1712	KSS-210A	
DENON	DCD-435	PCM1716E	KSS-213	
DENON	DCD-460	2 x PCM56P-L	KSS-210A	
DENON	DCD-480	2 x PCM61P-L - SM5840AP	KSS-240A	
DENON	DCD-485	PCM1735	KSS-213	
DENON	DCD-500	PCM54HP	KSS-123 / KSS-152	
DENON	DCD-500AE	PCM1791	KSS-213C	
DENON	DCD-520	2 x PCM56P - SM5807FP	KSS-150A	
DENON	DCD-560	2 x PCM61P-L	KSS-210A	

DENON	DCD-580	PCM67P	KSS-240A		
DENON	DCD-590	2 x PCM61P-L	- SM5840BP	KSS-240A	
DENON	DCD-595	2 x PCM61P-L	- SM5841BP	KSS-240A	
DENON	DCD-600	1 x PCM56P		KSS-152A	
DENON	DCD-610	1 x PCM56P-L		KSS-210A	
DENON	DCD-615	2 x PCM61P-L	- SM5841BP	KSS-240A	
DENON	DCD-620	2 x PCM61P-L		KSS-210A	
DENON	DCD-625	2 x PCM61P-L	- SM5841	KSS-240A	
DENON	DCD-635	2 x PCM61P-L	- SM5841BP	KSS-213B	
DENON	DCD-650F		PCM1700P		
DENON	DCD-655	2 x PCM1702		KSS-213	
DENON	DCD-660	2 x PCM61P	- CXD2551P	KSS-210A	
DENON	DCD-685	2 x PCM1702		KSS-213	
DENON	DCD-690	2 x PCM61P-L	- SM5840BP	KSS-240A	
DENON	DCD-695	2 x PCM61P-L	- SM5841BP	KSS-240A	
DENON	DCD-700	PCM54HP	KSS-123 / KSS-152		
DENON	DCD-700AE		PCM1791 Sanyo SF-P101N		
DENON	DCD-715	2 x PCM61P-L	- SM5841BP	KSS-240A	
DENON	DCD-725	2 x PCM61P-L		KSS-213	
DENON	DCD-735	2 x PCM61P-L	- SM5845AF	KSS-213B	
DENON	DCD-755AR		2 x PCM1702 - SM5845AF	KSS-213C	
DENON	DCD-755 II		2 x PCM1702	KSS-213C	
DENON	DCD-770	2 x PCM61P-L	- SM5840	KSS-240A	
DENON	DCD-800	1 x PCM56P	- SM5807CP	KSS-152A	
DENON	DCD-810	2 x PCM56P	- SM5807	KSS-150A	
DENON	DCD-815	2 x PCM61P		KSS-213	
DENON	DCD-820	2 x PCM56P		KSS-150A	
DENON	DCD-825	2 x PCM61P	- SM5841BP	KSS-240A	
DENON	DCD-830	2 x PCM56P		KSS-150A	
DENON	DCD-835	2 x PCM61P-L		Sharp H8147AF	
DENON	DCD-860	2 x PCM61P		KSS-210A	
DENON	DCD-890	2 x PCM61P		KSS-240A	
DENON	DCD-895	2 x PCM61P	- SM5841AP	KSS-240A	
DENON	DCD-900	1 x PCM56P-J		KSS-123A	
DENON	DCD-910	2 x PCM56P	- SM5807FP / PD0036	KSS-150A	
DENON	DCD-920	2 x PCM61P	- SM5818AP	KSS-210A	
DENON	DCD-960	2 x PCM61P	- SM5840AP	KSS-150A	
DENON	DCD-970	2 x PCM61P-J		KSS-240A	
DENON	DCD-980	2 x PCM61P		KSS-240A	
DENON	DCD-1000		1 x PCM53JP-V - CX23035	KSS-121A / KSS-123A	
DENON	DCD-1015		2 x PCM61P - SM5845AF	KSS-240A	
DENON	DCD-1100		PCM53JP-V / PCM54HP - CX23035	KSS-121A / KSS-123A	
DENON	DCD-1130		2 x PCM61P - SM5840	KSS-150A	
DENON	DCD-1290		2 x AD1861N-D / PCM61P - SM5840AP	KSS-240A	
DENON	DCD-1300		PCM54HP-J - SM5806P	KSS-123A	
DENON	DCD-1400		2 x PCM56P-J	KSS-152A	
DENON	DCD-1420		2 x PCM54HP - SM5813AP	KSS-150A / KSS-151A	
DENON	DCD-1450AR		2 x PCM1702-L - SM5845AF	Sharp H8147AF	
DENON	DCD-1460		2 x PCM61P - SM5818AP	KSS-150A	
DENON	DCD-1500		2 x PCM54HP-K - 2 x SM5801P	KSS-121A / KSS-123A	
DENON	DCD-1500 Mk II		2 x PCM56P-J - SM5807BP	KSS-151A	
DENON	DCD-1500AE		PCM1791 SACD		
DENON	DCD-1510		2 x PCM54HP - SM5813AP	KSS-150A	
DENON	DCD-1515AL		2 x PCM61P - SM5845AF	KSS-240A	
DENON	DCD-1520		2 x PCM64P - SM5813AP	KSS-151A	
DENON	DCD-1530		2 x PCM61P - SM5818AP	KSS-150A	
DENON	DCD-1550AR		2 x PCM61P - SM5845AF	Sharp H8147AF	
DENON	DCD-1560		2 x PCM1701P - SM5813AP	KSS-151A	
DENON	DCD-1600		2 x PCM56P-J	KSS-151A	
DENON	DCD-1610		2 x PCM64P - SM5803	KSS-151A	
DENON	DCD-1630		2 x PCM1701P - SM5813AP	KSS-150A	
DENON	DCD-1650G		4 x AD1862N-Z - SM5840AP - SM5828PKSS-150A / KSS-210A		
DENON	DCD-1650GL		4 x AD1862N-Z - SM5841AP - SM5828BP	KSS-150A / KSS-210A	
DENON	DCD-1650AR		4 x PCM1702 - SM5845AF	Sharp H8147AF	
DENON	DCD-1650SR		4 x PCM1704U		
DENON	DCD-1650AE		PCM1790 - SACD SACD		
DENON	DCD-1700		2 x PCM56P-K - SM5804D	KSS-123A	
DENON	DCD-1800		PCM53 Toshiba 4990076001 / 4998008000		
DENON	DCD-1800R		PCM53JP-V Toshiba 4990039006 / 4990074003		
DENON	DCD-1880AR		2 x PCM61P - SM5845AF	Sharp H8147AF	
DENON	DCD-2000		Hitachi HA16633P / PCM53JG-V	Hitachi (DA-1000)	
DENON	DCD-2000AE		PCM1790 - SACD SACD		
DENON	DCD-2060		2 x AD1861N-D - SM5840AP	KSS-240A	
DENON	DCD-2560		4 x AD1862N-D - SM5840AP - SM5828P	KSS-151A	
DENON	DCD-2560GL		4 x AD1862N-Z - SM5841AP - SM5828BP	KSS-150A / KSS-210A	
DENON	DCD-2700		4 x PCM1702-J - SM5845AF	KSS-240A	
DENON	DCD-2800AL		4 x PCM1702 - SM5845AF	Sharp H8147AF	
DENON	DCD-2880AR		4 x PCM1702 - SM5845AF	Sharp H8147AF	
DENON	DCD-3000		4 x PCM1702-J - SM5845AF	KSS-240A	
DENON	DCD-3300		2 x PCM56P-K - SM5804D	KSS-123A	
DENON	DCD-3500G		2 x PCM64P - SM5803AP	KSS-151A	
DENON	DCD-3500GL		4 x PCM58P-K - SM5803AP	KSS-151A	
DENON	DCD-3500RG		4 x PCM58P-K - SM5803AP	KSS-151A	
DENON	DCD-3520		2 x PCM64P - SM5803AP	KSS-151A	
DENON	DCD-3560		4 x PCM58P-K - SM5803AP	KSS-151A	
DENON	DCD-F100		SM5871AN	KSS-213C	
DENON	DCD-S1		4 x PCM1702-K	KSS-151A	
DENON	DCD-S10		4 x PCM1702-J - SM5845AF	KSS-240A	
DENON	DCD-S10 Mk II		4 x PCM1702-J	Sharp H8147AF	

DENON DCD-S10 Mk III 4 x PCM1704 + HDCD Sharp H8147AF
 DENON DCD-SA1 2 x PCM1792 - SACD SACD
 DENON DCM-270 PCM1716E KSS-213C
 DENON DCM-280 PCM1748
 DENON RCD-100 PCM1710
 DENON UCD-F1 2 x PCM61 KSS-240A
 DENON UCD-F10 2 x PCM61 KSS-240A
 DENON DN-2000F NKS240A

DIATONE DP-1000H 2 x PCM56P-S MLP-4
 DIORA CD-502 TDA1543 CDM-4
 DIORA CD-504 TDA1311 CDM 12.1
 DIORA CD-704 TDA1301 - SAA7345 CDM 12.1
 DPA BIGGER BIT TDA1547 (DAC7)
 DPA ENLIGHTENMENT DRIVE Transport CDM12.1
 DPA LITTLE BIT SAA7350 - YM3414 - YM3623B
 DPA PDM 1 SAA7320
 DPA PDM 1.2 SAA7322
 DPA PDM 1.3 SAA7350
 DPA PDM 2 2 x TDA1547 - SAA7350
 DPA T1 Transport CDM-4/19
 DUAL CD20 CX20017 KSS-123A
 DUAL CD40 TD6705AP - TC9179F
 DUAL CD41 CX20017 KSS-123A
 DUAL CD100 2 x AD1861N / PCM61P - YM3433 KSS-210A
 DUAL CD115 MN6471M / MN6474A KSS-210A
 DUAL CD120 Hitachi HA16633P / PCM53JG-V Hitachi (DA-1000)
 DUAL CD130 PCM53JG-V - TM5001 (HD61902H) Hitachi (DA-1000)
 DUAL CD135 MN6471M / MN6474A KSS-210A
 DUAL CD1006 LC7881 - YM7121 KSS-210A
 DUAL CD1016RC MN6474 Hitachi HOP-M3
 DUAL CD1025 CX20017 KSS-123A ?
 DUAL CD1045 2 x AD1856N KSS-150A
 DUAL CD1050 2 x AD1856N KSS-150A
 DUAL CD1080 MN6471 / MN6474 KSS-150A / KSS-210A
 DUAL CD3600 YM3020 MLP-9
 DUAL CD5070 1 x PCM56P-J - CXD1130Q Sanyo SF-88
 DUAL CD5150 TDA1541A - SAA7220P/B CDM-4/19
 DUGOOD BOUNDLESS 4 x PCM1702 - DF1704 VAM 1201
 DUGOOD DAC-3 AK4394VF
 DUGOOD GLORY YEAR TDA1541A - SAA7220 VAM 1201
 DUGOOD NEW CENTURY AK4394 Philips

E

EAD CD-1000 2 x PCM63P-K - DF1700P Pioneer Stable Platter PEA1030
 EAD CD-1000 SERIES III 2 x PCM63P-K - PMD100 Pioneer Stable Platter PEA1030
 EAD DSP-1000 SERIES II 2 x PCM63P-K - DF1700P - CS8412-CP D/A converter
 EAD DSP-1000 SERIES III 2 x PCM63P-K - PMD100 D/A converter
 EAD DSP-7000 2 x AD1862N-J - SM5813AP D/A converter
 EAD DSP-7000 SERIES II 2 x PCM63P-K - DF1700P - CS8412-CP D/A converter
 EAD DSP-7000 SERIES III 2 x PCM63P-K - PMD100 D/A converter
 EAD DSP-9000 PRO 2 x PCM63P-K - PMD100 - CS8412-CP D/A converter
 EAD T-1000 Transport Pioneer Stable Platter PEA1030
 EAD T-7000 Transport Sony KHS-130A
 EASTSOUND CD-E3 CS4390 CDM 12
 EASTSOUND CD-E5 CS4390-KP VAM 1202
 ELECTROCOMPANIET ECC-1 CS4398 Philips
 ELECTROCOMPANIET ECD-1 CS4397 - CS8420 D/A converter
 EMT 981 PROFESSIONAL TDA1541A-S1 (Single Crown) CDM-1 Mk II
 EMT 982 PROFESSIONAL TDA1547 (DAC7) CDM-9 Pro
 ENSEMBLE DICHRONO DRIVE Transport TEAC VRDS CMK-3
 ENSEMBLE DICHRONO HI-DAC CS4397 D/A converter
 ENSEMBLE DIRONDO DRIVE Transport Philips CD-Pro 2 (VAM 1254)
 ENTECH NUMBER CRUNCHER 203.2 CS4329-KP - CS8412-CP D/A converter
 ENTECH NUMBER CRUNCHER 205.2 CS4329-KP - CS8412-KP D/A converter
 ESTONIA 001 2 x TDA1540P - SAA7030 CDM-2
 EXPOSURE CD Player TDA1545A CDM 12.4
 EXPOSURE CD 2010 PCM1716 KSS-213
 EXPOSURE CD 3010 2 x PCM1704 KSS-213
 EXPOSURE CD XXII 2 x PCM1704 Sony
 EZO FOG STAGE3 AD1853

F

FISHER AD-800 CX20017 / PCM51JG-V 4 180T00271 (Toshiba OPH-32)
 FISHER AD-834 PCM53JG-V - YM201F-K
 FISHER AD-840 PCM53JP-V MLP-1C
 FISHER AD-844 PCM53JP-V MLP-1C
 FISHER AD-850 2 x TDA1540D - SAA7030 OPH-32
 FISHER AD-935 LC7881 Sanyo SF-P1
 FISHER AD-9020 PCM67P - SM5840 KSS-210A
 FISHER AD-9030 2 x PCM56P - LC7860J - PD0050 Sanyo SF-88
 FISHER AD-9060 PCM67P - SM5840CP KSS-210A
 FISHER AD-M82 LC7880 Sanyo SF-88
 FISHER AD-M700 2 x TDA1540D - SAA7030 OPH-32
 FISHER AD-Z1 2 x PCM58P - YM3434 Sanyo SF-P1
 FISHER DAC-205 PCM56P
 FISHER FCD-2600PCM54HP
 FISHER FCD-3500PCM54HP
 FORSELL AIR REFERENCE AIR BEARING Transport CDM-9 Pro
 FUNAI CD 6600 YM3020

G

GRUNDIG CD9000 TDA1541A CDM4.11(□95.00)

GAMUT CD1 CS4390
GAMUT CD3 PCM1792
GRUNDIG CD1 FINEARTS SAA7341GP CDM 12.1
GRUNDIG CD3 FINEARTS TDA1547 - SAA7350 - SM5840AS CDM 12.1
GRUNDIG CD 23 TDA1549 - SAA7345GP CDM 12.1
GRUNDIG CD 30 2 x TDA1540D - M4551 (SAA7030) CDM-0
GRUNDIG CD 35 2 x TDA1540P - SAA7030 CDM-2
GRUNDIG CD 103 LC7881 Sanyo SF-90
GRUNDIG CD 360 LC78816 M - YM7121C (filter) Hitachi HOP-M3
GRUNDIG CD 435 LC78816 M - YM7121C (filter) Hitachi HOP-M3
GRUNDIG CD 660 LC7881 Sanyo SF-90
GRUNDIG CD-903 FINEARTS TDA1541A - SAA7220P/B CDM-2 / CDM-4
GRUNDIG CD-904 FINEARTS SAA7350 - YM3433 KSS-210A
GRUNDIG CD-905 FINEARTS JVC - JCE4302A JVC OPTIMA-5S
GRUNDIG CD 1000 FINEARTS 2 x DAC(TDA1547) - TDA1307 CDM 12.1
GRUNDIG CD 5200 TDA1543 CDM-4/19
GRUNDIG CD 5500 TDA1543 CDM-4/19
GRUNDIG CD 7500 2 x TDA1540D - SAA7030 CDM-0
GRUNDIG CD 7550 2 x TDA1540P - SAA7030 CDM-1
GRUNDIG CD 8100 TDA1541 CDM-2/29 / CDM-4/11
GRUNDIG CD 8150 TDA1543 CDM-4/19
GRUNDIG CD 8200 TDA1541 SAA7210 SAA7220 CDM2/10
GRUNDIG CD 8400 TDA1541 - SAA7220P/A CDM-2/10
GRUNDIG CD 8400 MK II TDA1541A - SAA7220P/B CDM-2 / CDM-4
GRUNDIG CD 9000 FINEARTS TDA1541A CDM-2/29 / CDM-4/11
GRUNDIG CD 9009 FINEARTS 2 x TDA1541A-S1 - CXD1244 CDM-1 Mk II

H

HALCRO EC800 PCM1794 DVD-ROM
HARMAN KARDON HD100 YM3020 - M50421PMLP-7
HARMAN KARDON HD200 YM3020 - M50422P Hitachi HOP-M14
HARMAN KARDON HD300 1 x PCM56P - YM3815 MLP-3C
HARMAN KARDON HD500 PCM53JP-V - YM2201F-K KSS-121B / KSS-123A
HARMAN KARDON HD710 MN6474 Samsung SOH-A1
HARMAN KARDON HD720 PCM1710U - LC78621 Sanyo SF-P101
HARMAN KARDON HD730 SAA7350 - YM3433 KSS-240A
HARMAN KARDON HD740 2 x PCM1702U - SM5843AP Sanyo SF-P101
HARMAN KARDON HD750 PCM1732U KSS-213C
HARMAN KARDON HD755 PCM1732 KSS-213C
HARMAN KARDON HD760 4 x PCM1702-K - PMD100 Sanyo
HARMAN KARDON HD800 2 x PCM56P - SM5807EP - M50422P Hitachi HOP-M14
HARMAN KARDON HD970 AD1955 DVD-ROM DVS DSL-710A
HARMAN KARDON HD7225 MN6474 KSS-150A / KSS-210A
HARMAN KARDON HD7300 1 x PCM61P - M50423FP KSS-150A
HARMAN KARDON HD7325 MN6474 KSS-150A / KSS-210A
HARMAN KARDON HD7400 1 x PCM61P - M50423FP KSS-150A
HARMAN KARDON HD7425 2 x PCM61P KSS-210A
HARMAN KARDON HD7450 MN6471M - M50423FP KSS-210A
HARMAN KARDON HD7500 MN6471M - M50423FP KSS-150A
HARMAN KARDON HD7525 4 x PCM61P KSS-210A
HARMAN KARDON HD7600 MN6471M - M50423FP KSS-150A
HARMAN KARDON HD7600 Mk II MN6471M - M50423FP KSS-210A
HARMAN KARDON HD7625 4 x PCM61P - SM5840 KSS-210A
HARMAN KARDON HD7725 4 x PCM61P-K - SM5840CP KSS-210A
HARMAN KARDON FL8300 SM5871AS - CXD2507Q KSS-210A
HARMAN KARDON FL8350 TDA1305
HARMAN KARDON FL8370 PCM1732
HARMAN KARDON FL8380 PCM1732
HARMAN KARDON FL8400 SM5871AN - CXD1167Q KSS-210A
HARMAN KARDON FL8450 SAA7350GP - YM3433 KSS-210A
HARMAN KARDON FL8550 PCM1702
HARMAN KARDON FL8570 PCM61P
HCM ROYAL CDR3030 YM3020
HELIOS MODEL 1S CS4328 CDM 12.4 - Pro
HELIOS MODEL 2S CS4328 CDM 12.4 - Pro
HELIOS MODEL 3S CS4328 CDM 12.4 - Pro
HELIOS STARGATE CS4328 CDM 12.4 - Pro
HEYBROOK SIGNATURE PCM67
HI-VI SOUND CD-01 2 x SM5864AP - SM5841CS CDM 12
HIGH TECH GOLDLINE CX904 YM3020
HITACHI DA-005 1 x PCM54HP-J - 2 x SM5800P Hitachi HOP-M3TR
HITACHI DA-006 Hitachi HA12096NT Hitachi HOP-M14
HITACHI DA-007 Hitachi HA12096 - TM6002 (MSM6285) Hitachi HOP-M14
HITACHI DA-009 Hitachi HA12096NT - MSM6285 Hitachi HOP-M14
HITACHI DA-40 1 x PCM56P-L Hitachi HOP-M3
HITACHI DA-50 1 x PCM56P Hitachi HOP-M3
HITACHI DA-403 2 x PCM56P-L - CXD1088 Hitachi HOP-M3
HITACHI DA-404D 2 x AD1860N Hitachi HOP-M3
HITACHI DA-800 PCM53JG-V - TM5001 (HD61902H) 4972541
HITACHI DA-1000 Hitachi HA16633P / PCM53JG-V 4022542
HITACHI DA-2000 2 x PCM56P - YM3433 KSS-210A
HITACHI DA-3500 PCM53JP-V 4972541
HITACHI DA-6000 Hitachi HA12096NT Hitachi HOP-M14
HONOR TCD-1 1 x AD1865N - SM5843AP KSS-210A
HONOR TCD-2 2 x AD1865N - SM5843AP KSS-210A
HONOR TCD-50 1 x AD1865N - SM5843AP KSS-210A

I

ICEBERG CDK900PR LC7881 Samsung SOH-OT4 / KSS-210
INKEL CD-772 AD1852

INKEL CD-7080R 2 x PCM1702-K
 INKEL TEMA CD-1 TDA1547 CDM-9 Pro
 ITT HIFI 9015 CX20017 / PCM511JG-V 4 180T00271 (Toshiba OPH-32)
 ITT HIFI 9515 CX20017 Toshiba OPH-32
 ITT HIFI 9615 CX20017 Toshiba OPH-3

J

JADIS JD-1 Transport CDM-9 Pro
 JADIS SYMPHONIA TDA1545A Philips VAM 1210
 JAS-AUDIO MUSIK 1.2 PCM1732 KSS-213
 JAXON ACD-150 LC7880 - CXD1130 KSS-210 / Samsung
 JOLIDA JD-100A PCM1716E CDM 12.1
 JBR CD1 TDA1541A + TDA1542 CDM4
 JVC XL-E900 PCM56P OPTIMA-3
 JVC XL-V1 Hitachi HA16633P / PCM53JG-V Hitachi (DA-1000) / EGH4021251
 JVC XL-V3 PCM53JP MLP-1C
 JVC XL-V20 PCM53JP OPTIMA-1
 JVC XL-V22 PCM54 OPTIMA-2
 JVC XL-V131 LC7881 - YM7121B (filter) OPTIMA-5
 JVC XL-V151 JVC - JCE4501 - CXD2554P (filter) OPTIMA-5S
 JVC XL-V152 JVC - JCE4501 - CXD2554P (filter) OPTIMA-5S
 JVC XL-V221 LC7881 OPTIMA-5
 JVC XL-V242 JVC - JCE4501 - CXD2554P (filter) OPTIMA-5S
 JVC XL-V250 PCM56 OPTIMA-2
 JVC XL-V251 JVC - JCE4501 - CXD2554P (filter) OPTIMA-5S
 JVC XL-V252 JVC - JCE4501 - CXD2554P (filter) OPTIMA-5S
 JVC XL-V261 MN35500 OPTIMA-6
 JVC XL-V264 MN35500 OPTIMA-6S
 JVC XL-V300 PCM53JP MLP-1E
 JVC XL-V311 MN6471 OPTIMA-4S
 JVC XL-V450 PCM56 OPTIMA-2
 JVC XL-V464 MN35500 OPTIMA-6S
 JVC XL-V500 PCM53JP-V MLP-1D
 JVC XL-V550 PCM54HP - SM5806P OPTIMA-2
 JVC XL-V1100 2 x PCM54 OPTIMA-1
 JVC XL-Z232 MN35503 OPTIMA-6S
 JVC XL-Z555 2 x PCM56P - SM5807EP - YM3613B OPTIMA-4S
 JVC XL-Z1010 2 x PCM56P-J - YM3414 - YM3613B OPTIMA-4S
 JVC XL-Z1011 JVC - JCE4302 OPTIMA-5
 JVC XL-Z1050 JVC - JCE4501 - JCE4300 - YM3414 JVC OPTIMA-5S

K

KAVENT CD831 PCM1732 Philips VAM 1202
 KENWOOD DP-CD1 TD6709N
 KENWOOD DP-3E TC9218F
 KENWOOD DP-3J TDA1543 - PD0034 KSS-150A
 KENWOOD DP-3R PCM56P Toshiba TOPH7833
 KENWOOD DP-7I µPD6376CX - PD0060
 KENWOOD DP-7R Transport - CXD1125Q KSS-152A
 KENWOOD DP-28 TC9268P - LC78681E Sharp H8136
 KENWOOD DP-47 TD6720N - CXD1135QZ KSS-152A
 KENWOOD DP-87 TD6720N - CXD1135QZ Toshiba TOPH7833
 KENWOOD DP-235 2 x AD1856N / PCM56P - YM7121 Sanyo SF-90
 KENWOOD DP-460 TD6709N
 KENWOOD DP-492 TC9237BN - CXD1167Q KSS-210A
 KENWOOD DP-700 TD6705AP Toshiba OPH-32
 KENWOOD DP-730 2 x PCM56P - PD0050 KSS-210A
 KENWOOD DP-770 CX20152 - CX23035
 KENWOOD DP-840 TD6705AP Toshiba TOPH7810
 KENWOOD DP-850 CX20152 - CX23035 Toshiba TOPH7810
 KENWOOD DP-860 1 x PCM56P - CXD1130Q Toshiba TOPH7810 / TOPH7815
 KENWOOD DP-880SG 2 x PCM56P - CXD1088 Toshiba TOPH7815 / TOPH7833
 KENWOOD DP-990D CX20152 - CX23034 Toshiba TOPH7810
 KENWOOD DP-990SG 2 x PCM56P-K - SM5804D Kenwood J91-0341-05 / TAOHS-
 KENWOOD DP-1000 CX20152 - CX23035 MLP-3C
 KENWOOD DP-1001 TDA1547 - SAA7350GP - SM5840CP KSS-240A
 KENWOOD DP-1060 TC9268P - LC78681 Sharp H8136A
 KENWOOD DP-1080 LC78620E T25-0051-05
 KENWOOD DP-1100 CX20017 Toshiba OPH-32
 KENWOOD DP-1100D CX20152 - SM5802B Kenwood J91-0315-05
 KENWOOD DP-1100SG 2 x PCM56P-K - SM5804D Kenwood J91-0341-05 / TAOHS-
 KENWOOD DP-1510 2 x PCM56P-L - SM5807 KSS-150A / KSS-210A
 KENWOOD DP-2000 CX20152 - CX23034 MLP-3C
 KENWOOD DP-2010 2 x PCM56P-L KSS-210A
 KENWOOD DP-2030 TC9237N KSS-210A
 KENWOOD DP-2060 TC9268P Sharp H8136
 KENWOOD DP-2080 LC78620E (LC78820) Sharp H8151AF
 KENWOOD DP-3000 PCM56P-K
 KENWOOD DP-3010 2 x PCM56P-L - PD0036 KSS-210A
 KENWOOD DP-3030 1 x SM5860 - SM5840 KSS-210A
 KENWOOD DP-3060 SM5872BS KSS-240A
 KENWOOD DP-3080 SM5864 - SM5841 KSS-240A / T25-0010-05
 KENWOOD DP-3080 Mk II Kenwood KAN-03 - CXD2507AQ Sharp KCP1H
 KENWOOD DP-3090 Kenwood KAN-03 - CXD2507AQ Sharp KCP1H
 KENWOOD DP-3300D 2 x PCM56P-K - SM5804B Kenwood J91-0315-05
 KENWOOD DP-4030 1 x SM5860 - SM5840 KSS-210A
 KENWOOD DP-4090 Kenwood KAN-03 - CXD2507AQ Sharp KCP1H
 KENWOOD DP-5010 2 x PCM56P - SM5813AP KSS-210A
 KENWOOD DP-5020 2 x PCM1701P - SM5818AP KSS-210A
 KENWOOD DP-5030 CXD2552Q - SM5840CP - SM5827CP KSS-210A
 KENWOOD DP-5040 CXD2552Q KSS-210A

KENWOOD	DP-5050	SAA7350		
KENWOOD	DP-5060	SM5864AP - SM5841AP	KSS-240A	
KENWOOD	DP-5090	Kenwood KAN-05 - SM5843AS1	Sharp KCP1H	
KENWOOD	DP-6020	2 x PCM1701P - SM5818AP	KSS-150A	
KENWOOD	DP-7010	2 x PCM58P - SM5813AP	KSS-150A	
KENWOOD	DP-7020	2 x PCM1701P - SM5813AP	KSS-150A	
KENWOOD	DP-7030	CXD2552Q - SM5840CP - SM5827CP	KSS-210A	
KENWOOD	DP-7040	CXD2552Q - SM5840CP	KSS-210A	
KENWOOD	DP-7050	TDA1547 (DAC7) - SM5840CP	KSS-210A	
KENWOOD	DP-7060	TDA1547 (DAC7) - SM5843AP	KSS-240A	
KENWOOD	DP-7090	8 x PCM1702 - SM5843AS1	KSS-213B	
KENWOOD	DP-8010	2 x PCM58P - SM5813AP	DLBA2Z002B / J91-0377-05	
KENWOOD	DP-8020	2 x PCM1701P - SM5813AP	KSS-152 - Magnetic	
KENWOOD	DP-X9010	Transport - CXD1125Q	DLBA2Z002B / J91-0377-05	
KENWOOD	DPF-1010	CXD2587Q	KSS-213C	
KENWOOD	DPF-1030	LC78620E	Sharp HPC1LX	
KENWOOD	DPF-2010	CXD2587Q	KSS-213C	
KENWOOD	DPF-2030	LC78620E	Sharp HPC1LX	
KENWOOD	DPF-3010	Kenwood KAN-03 - CXD2587Q	KSS-213C	
KENWOOD	DPF-3030	AD1855 - KAN06	KSS-213C	
KENWOOD	DPF-7002	8 x PCM1702 - SM5843AS1	KSS-213B	
KENWOOD	L-03DP	CX890	Toshiba OPH-31	
KENWOOD	L-1000D	2 x CX20152 - CXD1144	KSS-152 - Magnetic	
KENWOOD	L-D1	TDA1547 (DAC7)	Kenwood CDM-21	
KENWOOD	LVD-Z1	TDA1547 (DAC7)		
KINERGETICS RESEARCH	KCD-20	TDA1541A-R1	CDM-2/10 / CDM-4/19	
KINERGETICS RESEARCH	KCD-30	TDA1541A	CDM-2/10 / CDM-4	
KINERGETICS RESEARCH	KCD-40	4 x AD1860N-K - CXD1144	CDM-2/10 / CDM-4/19	
KINERGETICS RESEARCH	KCD-55	Ultra	2 x UltraAnalog D20400A	
KODAK	PCD-5855	SAA7321	CDM-9	
KOREA	CHINA CD 022	KDA0316LN (Samsung)		
KOREA	HCD 630	Y3015		
KRELL	CD-1	CS4328-KP	CDM-1 Mk II	
KRELL	CD-DSP	2 x PCM61P-J + Motorola DSP	CDM-1 Mk II	
KRELL	CD-DSP Mk2	2 x PCM61P-K + Motorola DSP	CDM-1 Mk II	
KRELL	DT-10	Transport	CDM-4/36 Pro Metallic	
KRELL	KAV-250cd	2 x PCM1702 - PMD100	C.E.C. - Sanyo	
KRELL	KAV-280cd	4 x PCM1704 - DF1704	CDM 12 Pro / VAM 1201	
KRELL	KAV-300cd	2 x PCM1702-K - PMD100	VRDS CMK-4 - KSS-240A	
KRELL	KPS 20i	4 x PCM63P-K - Motorola XC56002F	CDM-9 Pro (CDM-9/60)	
KRELL	KPS 25s	2 x UltraAnalog D20400A - XC56009F	JVC EXU-901A	
KRELL	KPS 25sc	4 x PCM1704 - XC56009F - PMD100	JVC Pro	
KRELL	KPS 28c	4 x PCM1704K - PMD100	TEAC VRDS	
KRELL	KPS 30i	4 x PCM63P-K - PMD100	CDM 12 Pro / CDM 12.4	
KRELL	MD-1	Transport - SAA7210P	CDM-3	
KRELL	MD-2	Transport - SAA7210P	CDM-1 Mk II	
KRELL	MD-10	Transport - SAA7210P	CDM-3	
KRELL	MD-20	Transport - SAA7210P	CDM-1 Mk II	
KRELL	SACD STANDARD	3 x PCM1738	Philips 5.2 SACD	
KRELL	SBP-16X	2 x PCM58P-K + Motorola DSP-56001		
KRELL	SBP-32X	2 x PCM58P-K + 2 x Motorola XSP56001		
KRELL	SBP-64X	2 x PCM64P + 4 x Motorola DSP56001		
KRELL	STUDIO	2 x PCM63P-K + 2 x Motorola DSP56000		
KYOCERA	DA-01	2 x TDA1540D - SAA7030	HLPL 030010 (Toshiba OPH-31)	
KYOCERA	DA-9cx	2 x PCM56P-S - SM5804B	KSS-152A	
KYOCERA	DA-310cx	PCM54HP	KSS-152A	
KYOCERA	DA-410cx	CX20152		
KYOCERA	DA-710cx	2 x PCM56P-S - SM5804B	KSS-152A	
KYOCERA	DA-810	2 x TDA1540D - SAA7030	OPH32	
KYOCERA	DA-910	2 x TDA1540D - SAA7030	OPH32	
L				
LAVRY	DA10	AD1955 - AD1896	D/A converter	
LECTOR	CDP 3T	TDA1541A-S1 (Single Crown)	Philips CDM 12	
LECTOR	CDP 7T	2 x PCM63P	Philips CDM 12	
LECTOR	CDP 7TL	2 x PCM1704	Philips CDM 12	
LECTOR	DIGICODE	TDA1541A-S1 (Single Crown)	D/A converter	
LECTOR	DIGIDRIVE	Transport	CDM-4/19	
LINDEMANN	820	PCM1792 SACD	Sony KHM-230AAA	
LINDEMANN	822	PCM1792 SACD	Sony KHM-230AAA	
LINN	CD12 SONDEK	4 x PCM1702-K - PMD100	Philips	
LINN	GENKI	PCM1732U	Sanyo SF-91 / SF-P101N	
LINN	IKEMI	PCM1732U	Sanyo SF-91	
LINN	KARIK	CS4328-KS	Hitachi HOP-M3 / HOP-M3A	
LINN	MIMIK	CS4328	Hitachi HOP-M3 / Sanyo SF-91	
LINN	NUMERIK	2 x PCM63P-K - DF1700	D/A converter	
LINN	NUMERIK Mk 3	2 X PCM1702-K	D/A converter	
LO-D	DA-403D	2 x PCM56P - CXD1088	Hitachi HOP-M3	
LO-D	DA-404D	2 x AD1860N	Hitachi HOP-M3	
LO-D	DA-505D	2 x PCM61P	KSS-150A	
LO-D	DA-703D	2 x PCM56P-J + 2 x PCM56P	Hitachi HOP-M14	
LO-D	DAD-003	1 x PCM54HP-J - 2 x SM5800P	D/A converter	
LO-D	DAP-003	Transport	Hitachi HOP-M14	
LO-D	DAD-800	PCM53JG-V - TM5001 (HD61902H)	Hitachi (DA-1000)	
LO-D	DAD-1000	Hitachi HA16633P / PCM53JG-V	Hitachi (DA-1000)	
LO-D	DAD-3000	PCM53JP-V - TM5001 (HD61902H)	Hitachi (DA-1000)	
LO-D	DAD-5500	PCM54HP	Hitachi HOP-M14	
LOEWE	CD9000	2 x TDA1540D - SAA7030	CDM-0	
LUXMAN	D-01	1 x PCM56P-J - CXD1135QZ	KSS-152A / DLBA2Z	
LUXMAN	D03	CX20017	OPH-32	

LUXMAN	D-007	Transport – CXD1135QZ	KSS-152A / DLBA2Z
LUXMAN	D-90	TD6720N Toshiba TOPH7833	
LUXMAN	D-102	TD6709N Toshiba OPH-32	
LUXMAN	D-103	TD6705AP	Toshiba TOPH7810
LUXMAN	D-103U	2 x PCM1701P	KSS-152A
LUXMAN	D-105	TD6705AP	Toshiba OPH-32
LUXMAN	D-105U	2 x PCM1701P – SM5813AP	KSS-152A
LUXMAN	D-107U	2 x AD1860 – SM5813AP	KSS-152A
LUXMAN	D-109	1 x PCM56P-J	Sony BU-1C
LUXMAN	D-111	LC7880 – CXD1135QZ	KSS-152A / DLBA2Z
LUXMAN	D-112	1 x PCM56	
LUXMAN	D-113	1 x PCM56P – CXD1135QZ	KSS-152A / DLBA2Z
LUXMAN	D-113D	Transport – CXD1125QZ	KSS-152A / DLBA2Z
LUXMAN	D-115	1 x PCM56P-J – CXD1135QZ	KSS-152A / DLBA2Z
LUXMAN	D-322	2 x PCM61P – SM5841BP	KSS-240A
LUXMAN	D-351	AD1864N	KSS-150A
LUXMAN	D-373	AD1864N-J	
LUXMAN	D-404	TD6705AP	Toshiba TOPH7810
LUXMAN	D-405	TD6705AP	Toshiba OPH-32
LUXMAN	D-500	2 x PCM1701P – SM5813AP	CDM-3
LUXMAN	D-500X's II	TDA1541A-S1 (Single Crown)	CDM-3
LUXMAN	DU-7	CS4392 + NSdap	FN1242A
LUXMAN	DX-103	T1587	Toshiba OPH-32
LUXMAN	DX-104	CX890	Toshiba OPH-31
LUXMAN	DZ-03	2 x PCM1701P	KSS-152A
LUXMAN	DZ-92	LC7881	
LUXMAN	DZ-111	LC7881C – SM5807EP	KSS-152A / DLBA2Z
LUXMAN	DZ-112	2 x PCM1701P – SM5813AP	KSS-152A
M			
MAGNAVOX	CD2000	TDA1543	CDM-4/19
MAGNAVOX	CDB262	TDA1543A	CDM-4/19
MAGNAVOX	CDB460	TDA1541 – SAA7220P/A	CDM-2/10
MAGNAVOX	CDB465	TDA1541	CDM-2
MAGNAVOX	CDB470	TDA1541 – SAA7220P/A	CDM-2
MAGNAVOX	CDB471	TDA1541 – SAA7220P/A	CDM-2
MAGNAVOX	CDB472	TDA1541 – SAA7220P/A	CDM-2
MAGNAVOX	CDB473	TDA1541 – SAA7220P/A	CDM-4/11
MAGNAVOX	CDB480	TDA1543	CDM-4/19
MAGNAVOX	CDB500	TDA1543	CDM-4/19
MAGNAVOX	CDB560	TDA1541 – SAA7220P/A	CDM-2
MAGNAVOX	CDB600	TDA1543 – SAA7220	CDM-4/19
MAGNAVOX	CDB650	TDA1541 – SAA7220P/A	CDM-2
MAGNAVOX	FD1000	2 x TDA1540D – M4551 (SAA7030)	CDM-0
MAGNAVOX	FD1010	2 x TDA1540D – SAA7030	CDM-0
MAGNAVOX	FD1040	2 x TDA1540P – SAA7030	CDM-1
MAGNAVOX	FD1041	2 x TDA1540P – SAA7030	CDM-2/10
MAGNAVOX	FD1051	2 x TDA1540P – SAA7030	CDM-2/10
MAGNAVOX	FD2000	2 x TDA1540D – SAA7030	CDM-0
MAGNAVOX	FD2020	2 x TDA1540D – SAA7030	CDM-0
MAGNAVOX	FD2040	2 x TDA1540P – SAA7030	CDM-1
MAGNAVOX	FD2041	2 x TDA1540P – SAA7030	CDM-2
MAGNAVOX	FD3000	2 x TDA1540D – SAA7030	CDM-0
MAGNAVOX	FD3030	2 x TDA1540D – SAA7030	CDM-0
MAGNAVOX	FD3040	2 x TDA1540P – SAA7030	CDM-1
MANLEY	A TO D CONVERTER	2 x UltraAnalog D20400A	D/A converter
MANLEY	CS4328-KP	– CS8412	D/A converter
MANLEY	JUNIOR 20 Bit DAC	1 x UltraAnalog D20400A	D/A converter
MANLEY	Reference 20 Bit DAC	2 x UltraAnalog D20400A – SM5803AP	D/A converter
MANLEY	WAVE	2 x UltraAnalog D20400A	D/A converter
MANLEY	WAVE 24 Bit	2 x PCM1704	D/A converter
MARANTZ	CD-5L	1 x TDA1541 – SAA7220P/A	CDM-2/10
MARANTZ	CD7	SM5844 DSP56004 2XTDA1541A/S/N2 (double crown)	HDAM Philips CD-Pro (VAM1252)
MARANTZ	CD10	SAA7310 TDA1547 CDM4/D36	
MARANTZ	CD11LE/II	2xTDA1547 TDA1307 SAA7350	CDM4/D36 HDAM
MARANTZ	CD1010/20	CDM12.1	
MARANTZ	CD14	2 x TDA1547 – TDA1307	CDM 12.3
MARANTZ	CD15	TDA1547 CDM4-MD	
MARANTZ	CD-16 / CD-16SE	2 x TDA1547 – SM5803APT – SAA7350	CDM-4/36 Metallic
MARANTZ	CD16D	SAA7310 TDA1547 HDAM	
MARANTZ	CD-17	1 x TDA1547 – SM5841 – SAA7350	CDM 12.1
MARANTZ	CD17mkII	TDA1370 TDA1547(DAC7)	VAM1201 NJM2114/HDAM
MARANTZ	CD19	SM5872	
MARANTZ	CD23	2 x TDA1547	CDM9
MARANTZ	CD-25	2 x TDA1540P – SAA7030	CDM-2/10 / CDM-2/29
MARANTZ	CD273	CDM2	
MARANTZ	CD-32	SAA7350 – SM5840FP	CDM-4/19
MARANTZ	CD-34	2 x TDA1540P – SAA7030	CDM-1
MARANTZ	CD36	SAA7345 TDA1545	CDM12.1
MARANTZ	CD38	TDA1545	CDM12.1
MARANTZ	CD385	CDM4	
MARANTZ	CD40	SAA7310 SAA7220 TDA1541/A	CDM4/19
MARANTZ	CD-41	2 x SAA7321GP	CDM-4/19
MARANTZ	CD42	SAA7310 SAA7350 ?	CDM4//691.30209
MARANTZ	CD42 II	SAA7350 SM5840	CDM4
MARANTZ	CD43	SAA 7345 SM5872BS	CDM12.1/05 NJM4560
MARANTZ	CD45	TDA1540	CDM2/29
MARANTZ	CD46	SAA7345GP TDA1545	CDM12.1
MARANTZ	CD48	TDA1545//1549	CDM12.1
MARANTZ	CD50	TDA1541 SAA7220P/B	CDM4/19

MARANTZ CD52 SAA7350GP – SM5840FP CDM-4/19
MARANTZ CD52SE SAA7310 SAA7350(Bitstream) CDM4 NE5532
MARANTZ CD53 SAA7345 SM5872BS CDM12.1 NJM2114
MARANTZ CD56 SAA7220P/A TDA1541 CDM4/25
MARANTZ CD57/57 II SM5872 CDM12.1
MARANTZ CD583/93 CDM4/19
MARANTZ CD60 TDA1541 A CDM4/19 NE5534
MARANTZ CD62 SAA7350GP SAA7322 CDM-4/19
MARANTZ CD63 SAA7345 SM5872BS CDM12.1 HDAM
MARANTZ CD63II SAA7345 SM5872 CDM12.1
MARANTZ CD63mkII KI SAA7345 SM5872 CDM12.1
MARANTZ CD63SE SM5872BS CDM12.1
MARANTZ CD65 SAA7310 TDA1541 CDM4/25
MARANTZ CD65 II SAA7210 SAA7220B TDA1541 A CDM4/19
MARANTZ CD67 SAA7372 SM5872 CDM12.1
MARANTZ CD67SE SAA7372 SM5872 CDM12.1 HDAM
MARANTZ CD67II OSE SAA7372 SM5872 CDM12.1 HDAM
MARANTZ CD72 SAA7310 SAA7350(Bitstream) CDM4/19
MARANTZ CD72mkII SE SAA7310 TDA1547 CDM 4/28//CDM4/19 HDAM
MARANTZ CD73 SAA7000 TDA7010 TDA7020 TDA7030 2xTDA1540 CDM1
MARANTZ CD74 SAA7000/10 SAA7020 2xTDA1540 CDM1
MARANTZ CD75 TDA1541 CDM4/25
MARANTZ CD75mkII TDA1541A – SAA7220P/B CDM2-160
MARANTZ CD80 TDA1541 CDM1/mkII(CDM4.19) single opamps
MARANTZ CD84 TDA1540 CDM1
MARANTZ CD85 CDM1/mkII
MARANTZ CD-94 TDA1541A CDM-1
MARANTZ CD94/mkII TDA1541 CDM1
MARANTZ CD-95 2 x TDA1541A-S1 + 2 x SAA7220P/B CDM-1
MARANTZ CD-99SE 2 x TDA1541A-S1 (Single Crown) CDM-1
MARANTZ CD273 TDA1541 CDM-2
MARANTZ CD583 TDA1541A CDM-2 / CDM-4
MARANTZ CD650 TDA1541 – SAA7220P/A CDM-2/10 / CDM-4/25
MARANTZ CD873 CDM2-0500//CDM4/11
MARANTZ CD883 CDM4/19
MARANTZ CC3000 TDA1545
MARANTZ CD1010 SM5872BS CDM 12.1 (VAM 1201)
MARANTZ CD1020 SM5872BS CDM 12.1 (VAM 1201)
MARANTZ CD4000 SAA7378 TDA1545 VAM1201 NJM4560
MARANTZ CD5000 SAA7378 TDA1549 VAM1201 NJM4560
MARANTZ CD5001 CS4392 KSS-213C
MARANTZ CD5001-OSE CS4392 KSS-213C
MARANTZ CD5400CS4392 KSS-213C
MARANTZ CD5400-OSE CS4392 KSS-213C
MARANTZ CD6000 SAA7378 SM5872 VAM1201 NJM2114
MARANTZ CD6000KI SAA7372 SM5872BS VAM1201 HDAM
MARANTZ CD6000OSE SAA7372 2xSM5872 VAM1201 HDAM
MARANTZ CD6002 CS4398
MARANTZ CD7300 CS4396 VAM 1202
MARANTZ CDA-94 TDA1541A-S1 (Single Crown) D/A converter
MARANTZ CDV780 TDA1541A
MARANTZ PROJECT D-1 2 x TDA1541A-S2 (Double Crown) D/A converter
MARANTZ SA-1 4 x DAC7 (TDA1547) – TDA1307 CDM-10
MARANTZ SA-7S1 2 x SM5866AS SACDM-1
MARANTZ SA-11S1 / S2 SM5866AS SACDM-1
MARANTZ SA-12S1 2 x CS4397 SACD
MARANTZ SA-13S1 CS4397-KS SACD
MARANTZ SA-14 CS4397 SACD
MARANTZ SA-15S1 CS4397 SACD
MARANTZ SA-17S13 x CS4397 SACD
MARANTZ SA7001 CS4397 SACD
MARANTZ SA7001KI CXD1885Q CXD2753R CS4397 SACD
MARANTZ SA8001 CS4397 SACD
MARANTZ SA8260 3 x CS4397 SACD Sony KHM-230AAA
MARANTZ SA8400 CS4397 SACD HOP-1200R
MARK LEVINSON No 30 2 x UltraAnalog D20400 – SM5803AP D/A converter
MARK LEVINSON No 30.5 2 x UltraAnalog D20400A – PMD100 D/A converter
MARK LEVINSON No 30.6 4 x PCM1704 D/A converter
MARK LEVINSON No 31.5 Transport CDM 12 Ind
MARK LEVINSON No 36 4 x PCM1702-K – PMD100 - CS8412-CP D/A converter
MARK LEVINSON No 37 Transport CDM 12 Ind
MARK LEVINSON No 39 PCM1702 (PCM1704) CDM 12 Ind
MARK LEVINSON No 360S 4 x PCM1704 D/A converter
MARK LEVINSON No 390S 2 x AD1853 Philips CD-Pro (VAM 1252)
MBL 1521Transport CDM 12 Ind
MBL 1531CS4396 – CS8414 Philips CD-Pro 2LF (VAM 1254)
MBL 1621Transport CDM 12 Pro
McCORMACK CD DRIVE Transport CDM-4/19
McCORMACK DAC-1 CS4328-KP – CS8412-CP D/A converter
McCORMACK PRISM II TDA1541A-R1 – SAA7220P/B CDM-4/19
McCORMACK SST-1 Transport CDM 12
MCINTOSH NMCD201 CS4398 RAYMEDIA RMC RL-S880
MCINTOSH MCD751 Transport VRDS CMK-3 – KSS-151A
MCINTOSH MCD7000 2 x TDA1540 – SAA7030 CDM-1
MCINTOSH MCD7005 TDA1541A CDM-2/10
MCINTOSH MCD7007 TDA1541A-S1 (Single Crown) CDM-1
MCINTOSH MCD7008 2 x PCM1700P
MCINTOSH MCD7009 2 x TDA1547 – SAA7350 – SM5840AP VRDS CMK-3.2 – KSS-151A
MCINTOSH H MDA4000 2 x PCM1702 – SM5845AF D/A converter

MERACUS	IMAGO	Transport DM-9 / CDM-9 Pro		
MERACUS	TANTO	CS4327KS		
MERIDIAN	MCD	2 x TDA1540D - SAA7030	CDM-1	
MERIDIAN	MCD-Pro	2 x TDA1540D - SAA7030	CDM-1	
MERIDIAN	203	2 x SAA7321		
MERIDIAN	203 Mk II	TDA1547 (DAC7)		
MERIDIAN	206	TDA1541A-S1 (Single Crown)	CDM-4/21	
MERIDIAN	206B	TDA1547 (DAC7)	CDM-4/19	
MERIDIAN	206 BS	2 x SAA7321 - SAA7350	CDM-4/19	
MERIDIAN	206 DS	CS4328	CDM-4/19	
MERIDIAN	207	TDA1541A-S2 (Double Crown)		CDM-1 / CDM-4
MERIDIAN	208	2 x SAA7321		
MERIDIAN	500	Transport	CDM 12	
MERIDIAN	506	CS4328 - SAA7310	CDM 12.4	
MERIDIAN	506.24	CS4390	CDM 12	
MERIDIAN	507	CS4390		
MERIDIAN	507.24	AD1852JRC	Philips VAL 1250	
MERIDIAN	508	CS4329 - SAA7310	CDM 12.3	
MERIDIAN	508.24	CS4390	CDM 12.5	
MERIDIAN	588	CS4391	VAE 1250 / DSL-710A	
MERIDIAN	G06	AD1852	DVD-ROM DVS DSL-710A	
MERIDIAN	G07	AD1852	DVD-ROM DVS DSL-710A	
MERIDIAN	G08	AD1852	DVD-ROM DVS DSL-710A	
METAXAS	MASDAC	UltraAnalog D20400		D/A converter
METAXAS	MAS PHOS	Transport	CDM-9	
MHZS	CD66	PCM1742 KSS-213Q		
MICRO	CD-M1	2 x TDA1540D - SAA7030	HLPL 030010 (Toshiba OPH-31)	
MICRO	CD-M2	TDA1541	CDM-1	
MICRO	CD-M100	TDA1541A	CDM-1	
MICROMEGA	ARIA	AD1853	VAM 1202	
MICROMEGA	CD	AD1852	VAM 1202	
MICROMEGA	CD (2006)	AD1853	KSS-213Q	
MICROMEGA	CD-SE	AD1853	KSS-213Q	
MICROMEGA	CD132	AD1853	VAM 1202	
MICROMEGA	CD132-SE	AD1853	KSS-213Q	
MICROMEGA	CD F1	Transport	CDM-1 Mk II	
MICROMEGA	DATA	Transport	CDM 12	
MICROMEGA	DIALOG	TDA1547		D/A converter
MICROMEGA	DRIVE 1	Transport	CDM 12.4	
MICROMEGA	DRIVE 2	Transport	CDM 12.10	
MICROMEGA	DUO.CD.	Transport	CDM-9 Pro	
MICROMEGA	LEADER	SAA7321GP	CDM-4/19	
MICROMEGA	LOGIC	SAA7321	CDM	
MICROMEGA	MICRODAC	SAA7321GP - YM3623B		D/A converter
MICROMEGA	MICRODRIVE	Transport	CDM-9	
MICROMEGA	MINIUM	TDA1549	CDM 12.2	
MICROMEGA	PREMIUM18	CS4327	KSS-213C	
MICROMEGA	SOLO	TDA1547	CDM 12	
MICROMEGA	STAGE2	SAA7321GP	CDM 12.4	
MICROMEGA	STAGE4	TDA1305	CDM 12.3	
MICROMEGA	STAGE5	2 x TDA1305	CDM 12.1	
MICROMEGA	STAGE6	2 x TDA1305	CDM 12.3	
MISSION-Cyrus	CD 6S	PCM1738	CDM 12	
MISSION-Cyrus	CD 7	PCM1716	CDM 12.1	
MISSION-Cyrus	CD 8x	2 x PCM1738	Philips	
MISSION-Cyrus	DAC5	TDA1547		D/A converter
MISSION-Cyrus	Dacmaster	2 x AD1862N - SM5813APT - CS8412-CP		D/A converter
MISSION-Cyrus	dAD1	TDA1311	CDM 12.4	
MISSION-Cyrus	dAD1.5	TDA1311	CDM 12.1	
MISSION-Cyrus	dAD3	TDA1305	CDM 12.4	
MISSION-Cyrus	dAD3Q	AD1861	CDM 12.4	
MISSION-Cyrus	dAD7	AD1861	CDM-9	
MISSION	DAD7000	2 x TDA1540	CDM-1	
MISSION	PCM II	TDA1541A	CDM-4/11	
MISSION	PCM4000	TDA1541		
MISSION	PCM7000	TDA1541	CDM-2/10	
MITSUBISHI	DP-109	PCM56P		
MITSUBISHI	DP-103	CX20017	MLP-1C	
MITSUBISHI	DP-101	A3036	OPH-31	
MITSUBISHI	M-C5100	2 x PCM56P - YM3414	Sankyo SPM1001 - MLP-10-E2	
MONARCHY	AUDIO MODEL 18B	2 x AD1860N - YM3434		D/A converter
MONARCHY	AUDIO MODEL 22B	2 x PCM63P-K - SM5813APT		D/A converter
MONARCHY	AUDIO MODEL 22C	4 x PCM63P-K - DF1704		D/A converter
MONARCHY	AUDIO MODEL 24	2 x PCM63P-K - DF1704		D/A converter
MONARCHY	AUDIO MODEL 33	2 x PCM63P-K - SM5813APT		D/A converter
MONRIO	MJ PLAYER	CS4397	CD-ROM	
MONRIO	NAS-DAC	CS4397	VAM 1210	
MONRIO	TOP-LOADER	CS4390-KP	Philips CD-Pro (VAM 1252)	
MONRIO	TOP-LOADER 2	CS4390-KP	Philips CD-Pro 2M (VAM 1254)	
MUSE	MODEL TWO	2 x PCM63P-K - DF1700 - CS8412		D/A converter
MUSE	MODEL TWO PLUS	2 x PCM63P - PMD100 - CS8412		D/A converter
MUSE	MODEL FIVE	Transport	CDM 12.4	
MUSEATEX	BIDAT	TDA1547 - SAA7350GP		D/A converter
MUSEATEX	MELIOR BITSTREAM	SAA7350GP - YM3434 - YM3623B		D/A converter
MUSEATEX	MELIOR CD-D	CDM-1 Mk II	Transport	
MUSIC HALL	CD-25	PCM1732	CDM 12.10	
MUSIC HALL	CD25.2	PCM1738	VAM 1202	
MUSICAL FIDELITY	A2	YDC103		
MUSICAL FIDELITY	A3 DAC	PCM1738E - CS8420		D/A converter

MUSICAL FIDELITY	A3.2	PCM1738E	KSS-240A
MUSICAL FIDELITY	A3.5	PCM1738	Philips CDM 12
MUSICAL FIDELITY	C2	YDC103	
MUSICAL FIDELITY	CD1	SAA7323GP	- SAA7220P/B CDM-4/19
MUSICAL FIDELITY	DIGILOG	TDA1541A	D/A converter
MUSICAL FIDELITY	E60	YDC103	Sanyo SF-91
MUSICAL FIDELITY	E624	PCM1716	
MUSICAL FIDELITY	FCD	SAA7350	KSS-210A
MUSICAL FIDELITY	Nu-Vista	3D	PCM1738 Sony
MUSICAL FIDELITY	Tri-Vista	PCM1738	
MUSICAL FIDELITY	Tri-Vista	21	PCM1792 D/A converter
MUSICAL FIDELITY	X-24K	PCM1716	D/A converter
MUSICAL FIDELITY	X-RAY	PCM1716	KSS-240A
MUSICAL FIDELITY	X-RAY V3	PCM1732	Philips
MYRYAD	T-10	CS4327	Sony
MYRYAD	T-20	CS4327	Sony
MYRYAD	MC100	CXD2565	CDM 14 - Sony
MYRYAD	MCD600	CS4396	
MYRYAD	MXC6000	2 x CS4396	Sony
MYRYAD	Z110	CS4391	KSS-213B
N			
NAD	501	SAA7323GP	CDM-4/19
NAD	502	MN6474AM	- CXD1167Q KSS-210A
NAD	510	SAA7350	CDM 12.1 / KSS-210A
NAD	512	MN6474	- CXD1167Q KSS-150A / KSS-210A
NAD	514	MN6474	- CXD1167Q KSS-210A / KSS-212A
NAD	520	PCM1710U	Sanyo
NAD	522	PCM1710U	Sanyo SF-P101
NAD	523	SM5874	KSS-210
NAD	524	PCM1716E	Sanyo SF-P
NAD	5000	MN6471M	- YM3412B - CXD1167Q KSS-210A
NAD	5100	PCM56	MLP-10
NAD	5200	T1587	OPH-32
NAD	5255	TD6705AP	Toshiba OPH-32
NAD	5325	LC7881	
NAD	5420	MN6471MKSS	-210A
NAD	5425	MN6471MKSS	-210A
NAD	C520	PCM1710U	Sanyo SF-P101
NAD	C521	PCM1710U	Sanyo SF-P101
NAD	C521BEE	PCM1716	KSS-213
NAD	C525BEE	PCM1710U	KSS-213
NAD	C541	PCM1710U	Sanyo SF-P101N
NAD	C542	PCM1732U	KSS-213C
NAD	S500	CS4390	CDM 12.4
NAGRA	DAC	AD1853	D/A converter
NAIM AUDIO	CD1	TDA1541	CDM-2
NAIM AUDIO	CD2	TDA1541A	CDM-9
NAIM AUDIO	CD3	TDA1541A-S1	(Single / Double Crown) CDM-9
NAIM AUDIO	CD3.5	TDA1305	VAM 1205
NAIM AUDIO	CD5	TDA1305	CDM 12 / VAM 1205
NAIM AUDIO	CD5i	Philips UDA1330ATS	VAM 1202/12
NAIM AUDIO	CD5X	PCM1704	VAM 1201
NAIM AUDIO	CD555	PCM1704	- PMD200 CDM 12 Pro
NAIM AUDIO	CDI	TDA1541A-S1	(Single / Double Crown) CDM-4/27 / CDM-9 Pro
NAIM AUDIO	CDS 1	TDA1541A-S1	(Single Crown) CDM-4/25
NAIM AUDIO	CDS II	2 x PCM1702-K	VAM 1205
NAIM AUDIO	CDS 3	2 x PCM1704-K	VAM 1250
NAIM AUDIO	CDX	2 x PCM1702-K	+ PMD100 CDM 12 / VAM 1205
NAIM AUDIO	CDX2	PCM1704	
NAKAMICHI		1000mb/i	2 x PCM1700P-N - SM5813APT
NAKAMICHI	CD PLAYER 1	2 x PCM1700P-J	KSS-150A
NAKAMICHI	CD PLAYER 2	2 x PCM1700P	- SM5840CP KSS-210A
NAKAMICHI	CD PLAYER 3	1 x PCM1700P	- SM5840CP KSS-210A
NAKAMICHI	CD PLAYER 4	AD1864N	- SM5840BP KSS-150A / KSS-210A
NAKAMICHI	CDC-3A	TDA1541A	- CXD1088 Pioneer PWY1009 / PWY1010
NAKAMICHI	CDP-2 A/E	TDA1541A	- CXD1088 KSS-152A
NAKAMICHI	DAC-41	2 x PCM1702	- SM5841CP - YM3623B D/A converter
NAKAMICHI	DAC-100	4 x PCM1700P-K	D/A converter
NAKAMICHI	DAC-101	2 x TDA1541A-S1	(Single Crown) D/A converter
NAKAMICHI	DRAGON	CD/DAC	4 x PCM1704U-J - DF1704E Sanyo SF-91
NAKAMICHI	MB-1	2 x PCM1700P-N	- SM5813APT
NAKAMICHI	MB-1S	2 x PCM1700P	- SM5841CP Sanyo SF-91
NAKAMICHI	MB-2	2 x PCM1700P	- SM5840AP
NAKAMICHI	MB-2S	AD1868	- SM5841CP Sanyo SF-91
NAKAMICHI	MB-3S	AD1868	- SM5841CP Sanyo SF-91
NAKAMICHI	MB-4	LC78840	
NAKAMICHI	MB-4S	TDA1311A	- LC78840M Sanyo SF-91
NAKAMICHI	MB-5	LC78840	
NAKAMICHI	OMS-1	PCM56	KSS-150A
NAKAMICHI	OMS-2	1 x PCM54HP	
NAKAMICHI	OMS-3	1 x PCM54HP-J	- YM2601F-K KSS-121A / KSS-123A
NAKAMICHI	OMS-4	2 x PCM54HP-J	KSS-123A
NAKAMICHI	OMS-5	2 x TDA1540D	- SAA7030 HLPL 030020 / CA80255A
NAKAMICHI	OMS-5 II	PCM54HP	- SM5804B KSS-123A
NAKAMICHI	OMS-7	2 x TDA1540D	- SAA7030 HLPL 030020 / CA80255A
NAKAMICHI	OMS-7 II	2 x PCM54HP-K	- SM5804B KSS-123A
NAKAMICHI	OMS-20	TDA1541A	- CXD1088 KSS-152A
NAKAMICHI	OMS-30	1 x PCM54HP-J	- YM2601F-K KSS-121A / KSS-123A
NAKAMICHI	OMS-50	2 x TDA1540D	- SAA7030 HLPL 030020 / CA80255A

NAKAMICHI	OMS-50 II	PCM54HP – SM5804B	KSS-123A
NAKAMICHI	OMS-70	2 x TDA1540D – SAA7030	HLPL 030020 / CA80255A
NAKAMICHI	OMS-70 II	2 x PCM54HP-K – SM5804B	KSS-123A
NEC CD-10	2 x TDA1541A-S1 (Single Crown)		KSS-150A
NEC CD-410	PCM54HP KSS-152A		
NEC CD-430	PCM54HP KSS-150A		
NEC CD-509	PCM53JP-V KSS-121 / KSS-123		
NEC CD-600	NEC μPC655CA + NEC μPD6352CA KSS-123A		
NEC CD-607E	PCM53JP-V – YM2201F KSS-121 / KSS-123		
NEC CD-609	PCM53JP-V KSS-121 / KSS-123		
NEC CD-610	PCM54HP – μPD6350 KSS-123A		
NEC CD-620	TDA1541 KSS-150A		
NEC CD-705	PCM53JP-V 7971002 - OPH-32		
NEC CD-720	TDA1541 KSS-150A		
NEC CD-730	2 x TDA1541A KSS-150A		
NEC CD-803	PCM53JG-V 7971001 - OPH31		
NEC CD-810	2 x PCM56P-J + NEC μPD6352ACA KSS-123A		
NEC CD-816	2 x TDA1541A-S1 (Single Crown) KSS-150A		
NEC CD-830DS	2 x TDA1541A-S1 (Single Crown) Toshiba TOPH7833		
NEC CD-903	4 x PCM56P-K KSS-123A		
NESCO	HCD-50	CX20152 – CX23035	KSS-121A / KSS-123A
NIKKO	NCD 100	TD6705AP	Toshiba OPH-32
NORDMENDE SYSTEM	2000	Hitachi HA16633P / PCM53JG-V	Hitachi (DA-1000)
NORDMENDE SYSTEM	2003	PCM53JG-V – TM5001 (HD61902H)	Hitachi (DA-1000)
NORH	CD-1	PCM1728 CDM 12	
NORTH	STAR EXTREMO DAC	2 x PCM1792 – SM5849BF	D/A converter
NORTH	STAR MODEL 192 DAC	CS4396-KS – SM5849AF – CS8420-CS	D/A converter
NORTH	STAR M192 TRANSPORT	Transport – CS8420 – SM5849BF	Philips CD-Pro 2 (VAM 1254)

O

ONKYO DX-704 MN6472 (Technics MASH)
ONKYO DX-6430 YM3020
ONKYO DX-6470 PCM56
ONKYO DX-6550 Integra TC9219 (ONKYO 8D-3170-1)
ONKYO DX-6570 PCM58
ONKYO DX-6620 LC7881
ONKYO DX-7011 TC9237
ONKYO DX-7211 SM5874
ONKYO DX-7500 ONKYO 8S-3380-1
ONKYO DX-7711 Integra SM5864AP
ONKYO DX-7911 Integra SM5864AP
ORELLE CD100 TDA1541

P

PARASOUND CD M839 PCM56
PARASOUND C/DP1000 PCM67
PHILIPS AK601/630/640/729/CCD310/320 CDM4/19
PHILIPS CD-80 TDA1541
PHILIPS CD-85M TDA1541
PHILIPS CD-94M TDA1541
PHILIPS CD-100 TDA1540 CDM0
PHILIPS CD-101 TDA1540 CDM1
PHILIPS CD-104 TDA7000 TDA7010 TDA7020 TDA7030 2xTDA1540 CDM0/CDM1
PHILIPS CD-115/130/140 CDM4/19
PHILIPS CD-150/1 CDM2/29
PHILIPS CD-160 CDM4/25
PHILIPS CD-162/4 CDM4/19
PHILIPS CD-163 CDM12.1/05
PHILIPS CD-200 TDA1540 CDM0
PHILIPS CD-202 TDA1540 CDM0
PHILIPS CD-204 TDA1540 CDM0
PHILIPS CD-210 TDA1543 CDM4/19
PHILIPS CD-210 CDM4/19
PHILIPS CD-300/303 SAA7210 SAA7020 2xTDA1540 CDM1
PHILIPS CD-304 TDA1540 CDM1
PHILIPS CD-304 MkII (alu chassis) SAA7210 SAA7220P/A TDA1541 CDM1
PHILIPS CD-310 CDM4/19
PHILIPS CD-340 CDM4/19
PHILIPS CD-350 TDA7010 TDA7020 TDA7000 TDA1540 LM833 CDM2/29
PHILIPS CD-360 CDM2 //CDM4/25
PHILIPS CD-371/3 CDM4/11
PHILIPS CD-380 TDA1543/1/1A CDM4/19
PHILIPS CD-410 CDM12.1/05
PHILIPS CD-460 TDA1541 CDM2 //CDM4/25
PHILIPS CD-465 TDA1541
PHILIPS CD-470
PHILIPS CD-471 TDA1541 CDM4/11
PHILIPS CD-472 TDA1541 CDM4/11
PHILIPS CD-473 TDA1541 CDM4/11
PHILIPS CD-480/2 TDA1543 CDM4/19
PHILIPS CD-500/2 CDM4/19
PHILIPS CD-560 CDM2 //CDM4/25
PHILIPS CD-581/2 TDA1541 CDM4/19
PHILIPS CD-583 CDM4/19
PHILIPS CD-584 CDM2/10? CDM4? SAA7210 SAA7220P TDA1541
PHILIPS CD-586 CDM4/19
PHILIPS CD-600/4/5 CDM4/19
PHILIPS CD-610 SAA7310 SAA7220P TDA1541 CDM4/19
PHILIPS CD-604 TDA1543 CDM4/19
PHILIPS CD-614/15 TDA1543 CDM4/19
PHILIPS CD-618 Bitstream ? CDM4/19

PHILIPS CD-620 TDA1541 ? CDM4/19
PHILIPS CD-621 SAA7345
PHILIPS CD-624 SAA7323 CDM4/19
PHILIPS CD-630 SAA7220P/B TDA1541 CDM4/19
PHILIPS CD-634 Bitstream ? CDM4/19
PHILIPS CD-640 TDA1541
PHILIPS CD-650 SAA7210 SAA7220P/A TDA1541 CDM2/29//CDM4/25
PHILIPS CD-660 CDM4/11
PHILIPS CD-670 SAA7210 SAA7220P/A TDA1541 CDM4/11 LM833
PHILIPS CD-690 SAA7341 RCD1.2D
PHILIPS CD-692 SAA7341 CDM9/63
PHILIPS CD-710/720 CDM12.1 SAA7345 TDA1545
PHILIPS CD-721 SAA7345 TDA1545
PHILIPS CD-713/723 SAA7378 TDA1545 VAM1201 NJM4560
PHILIPS CD-733 CDM12.1/05
PHILIPS CD-740 TDA1549 CDM12.1/05
PHILIPS CD-750 SAA7345 SM5840 SAA7350 CDM12.1/05
PHILIPS CD-751 SAA7345 TDA1549 CDM12.1/15
PHILIPS CD-753 SAA7378 TDA1549 VAM1201 NJM4560
PHILIPS CD-771 CDM2-0500//CDM4/11
PHILIPS CD-780/1 CDM4/19
PHILIPS CD-782 TDA1541 CDM4/19
PHILIPS CD-820 SAA7220 TDA1541 A CDM4/19 LM833
PHILIPS CD-830 CDM4/19
PHILIPS CD-824/834 CDM4/19
PHILIPS CD-840 Bitstream CDM4/19
PHILIPS CD-850 TDA1541 CDM4/19 LM833
PHILIPS CD-880 TDA1541 S1 CDM1 mkII
PHILIPS CD-882 CDM1 mkII//691.20449
PHILIPS CD-883 CDM4/19
PHILIPS CD-910 SAA7341GP (4822-691-20768) CDM12.1/05//RCD1.2D
PHILIPS CD-911/921 SAA7345 TDA1549
PHILIPS CD-930/1 TDA1547 CDM9/44
PHILIPS CD-920/1 CDM12.1/05//RCD1.2D
PHILIPS CD-930/1 TDA1547 CDM9/44
PHILIPS CD-940 CDM9/44
PHILIPS CD-950 TDA1547 CDM9/44
PHILIPS CD-950/1 TDA1547 CDM9/44
PHILIPS CD-960 TDA1541 CDM1/mkII ? NE5534
PHILIPS LHH-100 TDA1547
PHILIPS LHH-500 TDA1547
PHILIPS LHH-600 TDA1547
PHILIPS LHH-800 TDA1547
PHILIPS LHH-1000 TDA1541
PHILIPS MAGNAVOX CDB-560 TDA1541
PHILIPS MAGNAVOX CDB-650 TDA1541
PIONEER DV-717 PE8001A
PIONEER PD40S PWY1010
PIONEER PD75 PD2028A
PIONEER PD93 PD2028A
PIONEER PD95 PD2028A
PIONEER PD-102/3 PEA1179
PIONEER PD-202/3 PEA1179
PIONEER PD-204 PD2026B
PIONEER PD-970 PEA1030
PIONEER PD-4050 PWY1010
PIONEER PD-4500 PCM1700 PEA1030
PIONEER PD-4700/5700/6500/67000/7700/8700 PEA1030
PIONEER PD-9700 CXD2500AQ NPC5840 2 x PD2028 PEA1030
PIONEER PD-4550 PCM1700P PEA1030
PIONEER PD-5100 PD0034 PWY1010
PIONEER PD-52 PEA1030
PIONEER PD-5300 PCM56 PWY1010
PIONEER PD-54 PEA1179
PIONEER PD-5500 PEA1030
PIONEER PD-5050 PWY1010
PIONEER PD-5700 PD2026A PEA1030
PIONEER PD-6050/6100/6300 PWY1010
PIONEER PD-65/6500/6700 PEA1030
PIONEER PD-7050 PWY1010
PIONEER PD-7300 PCM58P
PIONEER PD-7300/7500/7700/8700 PEA1030
PIONEER PDR-04 AKM4321
PIONEER PDR-609 PCM1716
PIONEER PDR-W739 PCM1716
PIONEER PDR-W839 PCM1716
PIONEER PDS-06 CXD2507AQ PD0236AD PD7009B PCM1702P-J
PIONEER PD-S303 PEA1030 NJM 4558/4580
PIONEER PD-S501 PEA1030 NJM 4558/4580
PIONEER PD-S502 PD2026B PEA1179 NJM 4558/4580
PIONEER PD-S503 PEA1179 NJM 4558/4580
PIONEER PD-S505 CXD2500 PD2029A PEA1030 NJM 4558/4580
PIONEER PD-S507 CXD2507aq PE8001A NJM 4558/4580
PIONEER PD-S602/3 PEA1179 NJM 4558/4580
PIONEER PD-S601/701 PEA1030 NJM 4558/4580
PIONEER PD-S702 PEA1179 NJM 4558/4580
PIONEER PD-S703 PD2029A PEA1179 NJM 4558/4580
PIONEER PD-S707 PEA1030 NJM 4558/4580
PIONEER PD-S801 PD2028

PIONEER PD-S802 PD0116A PEA1179
PIONEER PD-S901 PD2028B PEA1030
PIONEER PD-S909/990 PEA1030
PRIMARE D20 AKM4324
PRIMARE D302 4x PCM1702
PROCEED PCD2 PCM58P
PROTON AC423 LC78820
PROTON AC424 TDA1311A

Q

QUAD66 TDA1541A
QUAD77 CS4328

R

REGA PLANET PCM1710U
REVOX B225 TDA1540
REVOX B226 TDA1541 NE5534
REVOX C221 SAA7310
ROKSAN ATTESSA DP3P CS4328
ROKSAN CASPIAN TDA1305
ROTEL RCD-02 PCM1732
ROTEL DCM-9PRO PCM63
ROTEL RCD-855 TDA1541 CDM4/19
ROTEL RCD-856BX SAA7323
ROTEL RCD-865BX SAA7323
ROTEL RCD-945AX SAA7341GP T
ROTEL RCD-955AX SAA7210 SAA7220 TDA1541 LM833
ROTEL RCD-965BX SAA7323GP T
ROTEL RCD-970BX TDA1305T
ROTEL RCD-971 PCM63
ROTEL RCD-975 TDA1305T ROTEL RCD-991 PCM63P
ROTEL RCD-1070 PCM1732

S

SANSUI CD V1000 PCM56
SANYO CP489 LC7881
SEG CD200 YM3020
SHARP DX112 IR 3K16BM
SHARP DX650 LC7880
SHERWOOD CD1 TDA1547
SHERWOOD CD1060C D6372 CX
SHERWOOD CD1160R PCM56
SHERWOOD CD1192R YM4113B
SHERWOOD CDC2000C μ PD6376
SHERWOOD CDC2010RC μ PD6376
SHERWOOD CD4030R SAA7350BS
SIMAUDIO MOON ECLIPSE 4x PCM1704K
SONIC FRONTIERS SFCD1 UltraAnalog D20400A
SONY CDP-25/356 KSS120C
SONY CDP-203/30/45/50/55/65/70 KSS121A
SONY CDP-40 1x PCM54
SONY CDP-101 CX20017
SONY CDP-222ES PCM56P J
SONY CDP-222ESD CXD1125Q CXD1188Q TDA1541
SONY CDP-227ESD CXD1125 CXD1144 2XTDA1541
SONY CDP-228ESD CXD1165 CXD8003 CXD1144 PCM58P-J KSS151A
SONY CDP-302ES CX20152
SONY CDP-333ESA CXD2562
SONY CDP-333ESD TDA1541
SONY CDP-333ESJ CXD2562
SONY CDP-337ESD 2xTDA1541A
SONY CDP-497 CXD2561
SONY CDP-502 PCM54
SONY CDP-502ES CX20152
SONY CDP-552 PCM54
SONY CDP-553ESD PCM53JP-V K
SONY CDP-555ESA CXD2562
SONY CDP-555ESD TDA1541A
SONY CDP-555ESJ CXD2562
SONY CDP-620 CX23034 PCM54
SONY CDP-650 PCM54
SONY CDP-701ES CX20017
SONY CDP-777ESA CXD2562Q
SONY CDP-M18 CXD2500Q CXD2554M KSS240A
SONY CDP-MS1 CXD8594 + CXA8042AS
SONY CDP-R3 + DAS-R1a CXD2552Q + CXD2552
SONY CDP-X229ES CXD2562Q NKS240A
SONY CDP-X3000 CXD2562Q + CXA8042AS
SONY CDP-X303ES CXD2562Q
SONY CDP-X5000 CXD2515 CXD2562 + CXA8042
SONY CDP-X505ES CXD2562Q
SONY CDP-X33ES CXD2552Q
SONY CDP-X55ES CXD2552 KSS270A
SONY CDP-X777ES CXD2552BQ
SONY CDP-X779ES CXD2562
SONY CDP-X77ES CXD2552 KSS280A
SONY CDP-X7ESD PCM58P S KSS190A
SONY CDP-X900 CXA8042
SONY CDP-XA30ES CXD2562Q + CXA8042AS KSS160B
SONY CDP-XA50ES CXA8042AS
SONY CDP-XA55ES CXD8594Q + CXA8042S KSS310A
SONY CDP-XA5ES CXD2562Q + CXA8042AS

SONY CDP-XA7ES CXD2562 + CXA8042AS
SONY CDP-XB920 CXD8715 + CXA8355
SONY CDP-XB720E CXD8735N
SONY CDP-XB930 CXD8735N
SONY CDP-XE300 CXD8567
SONY CDP-XE330 CXD2529Q
SONY CDP-XE900 CXD8505 + CXA8055 KSS213B
SONY DAS-R1 4XTDA1541AS1 (single crown)
SONY CDX11/20/80/5B KSS160B
SONY CDXA15/20/30 KSS160B
SOUND WAVE CD1100 LC7881
STUDER D730/731 CS8412 SAA7310 SM5803 SAA7350 TDA1547 CDM4
SUDGEN OPTIMA TDA1543
SUDGEN SDA-1 TDA1541
SUDGEN SDT-1 TDA1541AS1 (single crown)

T

T+A CD1210R SM5864AP
TAG McLAREN CD20R CS4329
TALK ELECTRONICS THUNDER 3 CS4390
TASCAM CD201 MN6474
TEAC PD155mk2 Y3015
TEAC PD160 TC9218F 9A01026600
TEAC CPD3450SE YDC103LSI OPAxx
TEAC CPD3100/4100 KSS210A
TEAC PD365 YM7121B
TEAC VRDS 7 TDA1547
TEAC VRDS 8 PCM1702
TEAC VRDS 9 PCM1702
TEAC VRDS 10SE TDA1547
TEAC VRDS 25 AD1862J
TEAC ZD5000 PCM53
TECHNICS SL-P1 PCM53
TECHNICS SL-P2 PCM53
TECHNICS SL-P110 PCM54HP
TECHNICS SL-P120K E PCM54HP
TECHNICS SL-P272A MN6474
TECHNICS SL-P202/212/222 CDM4/19
TECHNICS SL-P177/277/377/477 A CDM4/19
TECHNICS SL-P1200 PCM54HP
TECHNICS SL-P360/70/460/70/570 CDM12.1/05
TECHNICS SL-PG480A MN662713 CDM12.1/05
TECHNICS SL-PG100/200/400/420/440/500/520/540 CDM4/19
TECHNICS SL-PJ28A MN6477 CDM4/19
TECHNICS SL-PJ24/26/27/28/37/325/46 CDM4/19
TECHNICS SL-PS620 CDM4/19
TECHNICS SL-PS670D MN6474 CDM12.1/05
TECHNICS SL-PS700 MN6474 SOAD70A
TECHNICS SL-PS740A CDM4/19
TECHNICS SL-PS770A MN6473 CDM12.1/05
TECHNICS SL-PS840/900A SOAD70A
THETA DSP PCM67
THOMSON LAD300 TD6720N
THULE CD100 CS4303
THULE SPIRIT PCM1715U
TOSHIBA XR40 TD6705AP

U

UHER UCD-210 LC7882
UNIVERSUM CD4682 PCM56
USHER CD-100 PCM1732

W

WADIA 6 4 x AD1864N-K / 4 x PCM63P-K VRDS CMK-3 - KSS-151A
WADIA 7 It's a Transport VRDS CMK-2 - KSS-151A
WADIA 8 It's a Transport VRDS CMK-3 - KSS-151A
WADIA 12 2 x AD1865 It's a DAC
WADIA 15 4 x PCM63P-K It's a DAC
WADIA 16 PCM1702 TEAC VRDS CMK-3
WADIA 21 4 x PCM1702-K VRDS CMK-4 - KSS-240A
WADIA 23 2 x AD1865N - XC3042A Pioneer Stable Platter
WADIA 27 PCM1702 It's a DAC
WADIA 270 It's a Transport VRDS CMK-3.2 - KSS-151A
WADIA 301 2 x PCM1704 Pioneer Stable Platter PEA1343
WADIA 302 2 x PCM1704-K Philips VAE 1250
WADIA 830 4 x PCM1702 Pioneer Stable Platter PEA1343
WADIA 831 PCM1704 Pioneer Stable Platter
WADIA 850 2 x PCM1702-K VRDS CMK-4-a - KSS-240A
WADIA 860 4 x PCM1702 VRDS CMK-3.2 - KSS-151A
WADIA 861 4 x PCM1704-K VRDS CMK-3.2 - KSS-151A

Y

YAMAHA CD-1 2 x CX890 / CX20017 OPH-31
YAMAHA CD-1a CX20017 OPH-31
YAMAHA CD-2 uPD4016 YM2201 PCM53JP MLP-1C
YAMAHA CD-3 YM5531 YM2201 PCM53JP
YAMAHA CD-2000 YM2601 YM3811 2XSM5800 1XPCM54 2XLA3170 2XNJM5532 TAOHS-DG1
YAMAHA CD-4050 2 x PCM58P - YM3414 TAOHS-JP3
YAMAHA CD-5050 4 x PCM58P-J TAOHS-HG1 / NX602610
YAMAHA CDC-625 PCM69
YAMAHA CDC-775 YAC514-F - MN35511 Sharp
YAMAHA CDV-1070 1 x PCM56P-J
YAMAHA CD-X1 PCM53JP-V - YM2201F - YM3511F MLP-1C

YAMAHA	CD-X2	YM4006 / PCM53JP-V – YM2201F-K	MLP-2C
YAMAHA	CD-X3	PCM54HP – YM2201	MLP-3C
YAMAHA	CDX-10	YAC514 KSS-210A	
YAMAHA	CDX-390	MN35511 KSS-210A	
YAMAHA	CDX-393	MN66271RA	KSS-213C
YAMAHA	CDX-396	MN35511AL	KSS-213C
YAMAHA	CDX-397	CS4392 KSS-213C	
YAMAHA	CDX-400	1 x PCM56P	MLP-7
YAMAHA	CDX-410	PCM56	
YAMAHA	CDX-420	PCM56	
YAMAHA	CDX-450	KSS210A	
YAMAHA	CDX-470	YDC103 KSS210A	
YAMAHA	CDX-480	MN66271 KSS210A	
YAMAHA	CDX-490	MN66271R	
YAMAHA	CDX-580	YAC514 KSS210A	
YAMAHA	CDX-590	YAC514	
YAMAHA	CDX-593	YAC514	
YAMAHA	CDX-700	PCM56	
YAMAHA	CDX-750/860	KSS210A	
YAMAHA	CDX-880	YAC514 KSS210A	
YAMAHA	CDX-900	PCM56	
YAMAHA	CDX-890	YAC514	
YAMAHA	CDX-893	YAC514	
YAMAHA	CDX-993	YAC514F	
YAMAHA	CDX-1100	PCM56	
YAMAHA	CDX-2020	PCM58	
YBA	YC201	Wolfson WM8740	
YOKO	F-420R	PCM56P	
Z			
ZANDEN	MODEL 2000	Transport Philips CD-Pro 2 (VAM 1254)	
ZANDEN	MODEL 5000	TDA1541A-S2 (Double Crown)	D/A converter
ZENITH	CV-680	PCM53JP-V	MLP-1C